

Service
Service
Service



EPA POLLUTION PREVENTER

DDC/Power saving/TCO
User-friendliness Control

107P2 CM25 GSIII



107P20/00

Service Manual

Horizontal frequencies
30 - 92 kHz

TABLE OF CONTENTS

Description	Page	Description	Page
Important Safety Notice -----	2	Video Panel(A) Schematic Diagram & Waveforms---	28
Technical Data -----	3	Video Panel C.B.A-----	29
Installation -----	4	Main Panel C.B.A. (B1,B2,B3,C)- -----	30
OSD Menu tree structure -----	5	Deflection Panel (B1) Schematic Diagram-----	31
OSD Adjustments -----	6-14	H-Voltage(B2) Schematic & Waveforms(B1,B2,B3)--	32
Warning and Notes -----	15	CPU(B3) Schematic Diagram -----	33
Mechanical Instructions -----	16	Power Supply(C) Schematic Diagram & Waveforms-	34
Wiring Diagram-----	17	Repair Tips -----	35
DDC Instructions -----	18~21	Exploded View -----	36
DDC Data-----	22	Recommanded parts List -----	37
Electrical Adjustments -----	23~25	Spare parts list-----	38~44
Safety test requirements (Hipot & Ground)-----	26	General product specification-----	45~67
Block Diagram & Control Panel C.B.A.-----	27	Repair flow chart-----	68~75
		LightFrame for Windows-----	76~77

REFER TO BACK COVER FOR IMPORTANT SAFETY GUIDELINES

SAFETY NOTICE

ANY PERSON ATTEMPTING TO SERVICE THIS CHASSIS MUST FAMILIARIZE HIMSELF WITH THE CHASSIS AND BE AWARE OF THE NECESSARY SAFETY PRECAUTIONS TO BE USED WHEN SERVICING ELECTRONIC EQUIPMENT CONTAINING HIGH VOLTAGES.

CAUTION: USE A SEPARATE ISOLATION TRANSFORMER FOR THIS UNIT WHEN SERVICING.

GB 3138 106 10113



Go to cover page

Proper service and repair is important to the safe, reliable operation of all PHILIPS Company** Equipment. The service procedures recommended by PHILIPS and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully Read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper Service methods may damage the equipment. It also is important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. PHILIPS could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, PHILIPS has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by PHILIPS must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

* * Hereafter throughout this manual, PHILIPS Company Will be referred to as PHILIPS.

WARNING

Critical components having special safety characteristics are identified with a  by the Ref. No. in the parts list and enclosed within a broken line* (where several critical components are grouped in one area) along with the safety symbol  on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from PHILIPS. PHILIPS assumes no liability, express or implied, arising out of any unauthorized modification Of design. Servicer assumes all liability.

* Broken Line      

FOR PRODUCTS CONTAINING LASER :

- DANGER-** Invisible laser radiation when open.
AVOID DIRECT EXPOSURE TO BEAM.
- CAUTION-** Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- CAUTION-** The use of optical instruments with this product will increase eye hazard.

TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE MANUAL.

◀◀ Go to cover page

Introduction

Philips LightFrame™ feature enriches the experience of pictures and video on a Philips CRT (picture tube) monitor. This highlighting is done by boosting the brightness and sharpness on a selected region of the monitor screen. Since high brightness and sharpness are not preferred for most standard Windows applications, this special feature will only be active in certain circumstances. So that you can control these circumstances, a special program and icons will be installed in your Windows operating systems.

Notes

Philips LightFrame™ will only work with monitors that have been built to use this software. Earlier Philips monitors or other manufacturers' monitors will not work with this special software. It is recommended that you install this software only on a Philips monitor designed to use it. These monitors can be identified by the LightFrame™ logo on the front of the monitor.

This software is not designed for use with LCD flat screen monitors.

LightFrame™ will work with true Windows-based programs and DOS-based programs that operate in a Window's environment. It will not work with DOS-based programs operating only in a DOS environment.

Definitions

The following list contains definitions for frequently used words.

Highlighted window: The selected window on which LightFrame™ is active.

Highlighted area: The selected rectangle (area) on which LightFrame™ is active.

Compatibility

This version of LightFrame™ is compatible with
Windows 95
Windows 98
Windows NT
Windows 2000 Professional Edition.

Language Selection

While English is the default language of LightFrame™, the User Interface can be set up to operate in Dutch, French, German, Italian, Portuguese, or Spanish.

Installation

- 1) To install LightFrame™, place the CD in the CD-ROM drive.
- 2) Next, when the menu of items on the CD appears on your screen, click on 'Install LightFrame™'.
- 3) Now, follow the on-screen prompts to properly install the program. The software checks to see if you have a compatible monitor. You must say yes to the license agreement for the software to install.
- 4) After installation, LightFrame™ automatically loads and the icon appears in the taskbar.

Notes

LightFrame™ is installed in the Start menu, under Programs. Unless otherwise selected during installation, LightFrame™ is installed in "C:\Program Files\Philips\LightFrame." A shortcut is installed in the StartUp folder and on the desktop. (If needed, LightFrame™ can be operated manually from the StartUp folder.)

If LightFrame™ detects that your monitor is not LightFrame™ compatible, an message appears on the monitor screen. See Error Message number 1 under the heading Error Messages. If you see this message, you can select to abort or continue the installation. However, if you continue the installation, LightFrame™ will probably not work on the monitor.

Uninstall

Should you need to remove the LightFrame™ software, please follow these steps.

- 1) First, click on the Start Menu.
- 2) Next, highlight Settings.
- 3) Then, click on Control Panel.
- 4) Now, click on Add/Remove Programs
- 5) Finally, select LightFrame from the list and then click on the Add/Remove button.

Operating LightFrame™

After installation, LightFrame™ starts up automatically whenever the computer is started. At system start up, LightFrame™ checks the selected resolution of the monitor and if the monitor is LightFrame™ capable.

Icon and Colors

An icon of a monitor represents LightFrame™ on your desktop. This icon appears as a shortcut on the Windows desktop. LightFrame™ has three (3) modes of operation: Active, Inactive, and Suspended. The same icon with a different color in its center represents each mode.

Active = The LightFrame™ icon has bright green center.

Inactive = The icon has a gray center.

Suspended = The icon has a yellow center with a red cross.

Notes

An active window must be 100% visible, i.e. it must be on top of all other windows or areas. If any part of another window or area overlaps a highlighted window, LightFrame™ automatically suspends operation. That means the icon goes from a green center to a yellow on with a red cross and the feature ceases. Once that window or area is removed and the original highlighted window is on top again, LightFrame™ automatically re-engages and the icon regains its bright green center.

An active window must also be 100% on the monitor's viewing area. If part of a highlighted window moves off the monitor's viewing area, LightFrame™ automatically goes into the Suspended mode. If part of a window is off the viewing area, you will not be able to use LightFrame™ on that window.

Only one window or area at a time can be highlighted.

How To Activate LightFrame™

- 1) Click on the LightFrame™ icon in the systemtray (the area to the far right in the taskbar). . The icon will turn from gray to a green center.
- 2) Guide the mouse to the window you want displayed. As you move the mouse, the cursor changes to a small arrow with a light bulb.
- 3a) Click on the window you want to have highlighted. The brightness and sharpness are automatically adjusted.
- 3b) If you want to highlight only an area of a window, click on the left mouse button and drag the cursor over the area to be highlighted while holding the mouse button. A rectangle forms around the area. When the area is encompassed by the rectangle, release the mouse button and the area becomes highlighted.

How to Deactivate LightFrame™

To deactivate, click on the LightFrame™ icon in the System Tray of the Taskbar. The light in the middle of the icon turns gray and LightFrame™ is deactivated.

Note

If a highlighted window is closed before LightFrame™ is deactivated, LightFrame™ is automatically deactivated.

◀◀ Go to cover page

Right-Click Features

On the LightFrame™ icon in the taskbar, click the right-side mouse button to bring up a menu from which you can select:

About... which tells you something about LightFrame™

Help which takes you to the Help screen where you can find additional information

Exit which exits the LightFrame™ Program.

If you select exit and the color in the center of the icon is green, it will turn gray and LightFrame™ is deactivated. If you select exit an Exit message appears asking you if are sure you want to exit. Select "Yes" to exit or "No" to abort the exit. If you select Yes, you can always restart LightFrame™ by clicking on the desktop shortcut icon.

LightFrame™ is Suspended When . . .

Screensaver, Sleep mode, Deep Sleep (Power Off) mode is Activated

LightFrame™ goes into the Suspended mode as soon as a screensaver becomes active on your computer. This is true even though the monitor icon may still have a green center. LightFrame™ becomes active again as soon as the screen is reawakened and the screensaver quits.

The same is true when the computer goes into Sleep mode or Deep Sleep (Power Off) mode. LightFrame™ goes into Suspended mode and reawakens when the monitor is reawakened.

Screen or Area is Minimized

LightFrame™ suspends when a highlighted window is minimized. LightFrame™ reactivates when the highlighted window is again maximized or restored to its previous size.

Another Window or Area Overlaps Highlighted Window or Area

LightFrame™ suspends if a window that is not highlighted overlaps a highlighted window. LightFrame™ reactivates once the highlighted window is again on top.

Miscellaneous

Monitor Turned Off

If the monitor is "hard powered off" while a window or area is highlighted and then hard powered on again, LightFrame™ is no longer active. The icon may still show the feature as still active. In this case, you have to exit LightFrame™ and restart it via the icon on the desktop or the Start menu.

If the Monitor is Detached and Another Monitor is Attached

If the monitor is detached from the computer while a highlighted window or area is displayed and then another monitor is attached, the system will have to be rebooted so that Philips' LightFrame™ can detect the monitor's LightFrame™ capabilities and store the setup information about the new monitor. If the monitor is not LightFrame™ capable, an Error message appears. See Error Message 2 under the heading Error Messages. You can abort or continue the set up. However, if you continue, LightFrame™ may not work with the monitor.

Error Messages

You may see this message when you install LightFrame™.

Error Message 1 dialog box here

LightFrame™ cannot detect a monitor which supports this feature. You can still proceed with the software installation but LightFrame™ might not run on your system.

You may see this message when you try to switch monitors.


Error Message 2 dialog box here

LightFrame™ cannot detect a monitor which supports this feature. You can still start the software but LightFrame™ may not work.

Repair Flow Chart

Go to cover page

A. Power Supply Failure



B. Video Repair Flow

rough check for R, G, B
1. video input= 0.7V
2. 7301 video output =2.5V
3. 7701 video output= 35V swing

1.Symptom :
(with white pattern)
no picture
green LED on

check heater
=-6.1V

check
EHT=25KV

check blanking
7503 pin16

Ok

check
VG1 < -150V

check
R,G,B output
30<2725<80
30<2733<80
30<2753<80

Ok

check DC restoration
7722,7732,7752
7721,7731,7751

check
VG2 > 350V

check Xray prot.
7503 pin2

No

No

check blanking
7503 pin16

Ok

2.Symptom :
no video (or dim),
only raster with/without retrace line
green LED on

check Vg1
Vg1 = 0V

No

turn down Vg2

check cathod
+80V/+180V

check 7301 pin24
2V< ABL < 5V

check 7301
pin 6,8,10
input swing

check 7701
pin8,9,11
input swing

check 7701
pin 1,3, 5
output swing

No

replace IF
cable

Ok

replace 7701

check 7301
pin11 FLB

check
7503 pin16

check 7301
pin5 CLBL

replace 7301

No

Ok

3. Sympton :
no OSD or
OSD out of sync.

check 7301
pin 2,3,4 input

No

check
7304 pin10
VFLB

check 7304
pin2 VCO
pin3 RP

Ok

check
7301 pin1

check
7304 pin12

Ok

No

replace 7301

check 7304
pin5 HFLB

Ok


check 7304
pin 7,8(IIC)

No

replace 7304

Repair Flow Chart (Continued)

C. Horizontal deflection
output repair flow :



D. Vertical Deflection Failure

basic check
+13/-13V

Symptom :
one horizontal line
V_size is abnormal
too large/small (small)

check
7503
pin 12, 13

Ok

check
+78V,
good?

Ok

check 7404
pin1,pin7 ramp
exist ?

No

check
3401,3402




No

replace
7503




Repair Flow Chart (Continued)


Go to cover page

E. CPU
check list




Hor. Freq.(KHz)	Q5	Q4	Q3	Q2	Q1
~33.24	0	0	0	0	0
33.24~36.51	0	1	0	1	0
36.51~40.60	0	1	1	0	0
40.60~45.07	1	0	0	0	0
45.07~47.62	1	0	0	1	1
47.62~51.49	1	0	1	1	1
51.02~55.07	1	0	1	1	1
55.07~61.96	1	1	0	0	0
61.96~66.29	1	1	0	1	0
66.29~71.00	1	1	0	1	1
71.00~76.00	1	1	1	0	0
76.00~82.96	1	1	1	0	1
82.96~89.00	1	1	1	1	0
89.00~0xffff	1	1	1	1	1






Repair Flow Chart (Continued)

Go to cover page





PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

CM25 - 107P2 General Specification (Sheet 590)

FEATURES / BENEFITS

- Extremely high MTBF (over 75K Hours, exclude. CRT).
- User friendly OSD display for mode identification and adjustment
- Professional look, with non-flammable cabinet (94V-0).
- Better display performance.
 - . Super Flat/square display tube
 - . Finer CRT dot pitch (0.25 mm)
 - . Full screen size application
 - . Real multi - freq.
- Power saving management system.
- VESA DDC1 /2B
- Picture tilt control
- Low emission TCO99

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME K.C. Huang		SUPERS.		23	590 — 1 10 A4
TY	CHECK	DATE 00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.		

PHILIPS



All rights stitcity reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

INDEX
=====

1.0	Introduction
2.0	General description
2.1	General condition
3.0	Electrical characteristics
3.1	Signal interface
3.1.1	Input requirements
3.1.2	Signals input.
3.1.3	Factory pre-set modes
3.2	Timing requirements
3.2.1	Horizontal scanning
3.2.2	Vertical scanning
3.3	Power supply
3.4	Power saving management system
3.5	CRT description
3.6	RGB amplifier
3.6.1	Video amplifier
3.6.2	Brightness and contrast
3.7	Variation of image size
3.8	Degaussing
3.9	Phosphor protection
3.10	Low emission requirements (TCO-99)
3.11	Display data channel : DDC1/2B (VESA STANDARD)
4.0	Display
4.1	Display resolution
4.2	Image size
4.3	Image centering deviation
4.4	Picture shift control range
4.5	Geometric distortions
4.6	Picture tilt
4.7	Image non-linearity

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	2
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

- 4.8 Mis-convergence
- 4.9 Focus check
- 4.10 Luminance uniformity
- 4.11 White color adjustm ent
- 4.12 Color tracking on full white pattern
- 4.13 Purity
- 4.14 Moire
- 5.0 Mechanical characteristics
- 5.1 User controls (at front)
- 5.2 Connector and cables
 - 5.2.1 Power Cord
 - 5.2.2 Signal Cable
- 5.3 Foot Assembly
- 6.0 Connector and cable
- 7.0 Environmental characteristics
 - 7.1 Susceptibility of display to external environment
 - 7.1.1 Operation limits
 - 7.1.2 Transportation packages
 - 7.2 Display disturbance from external environment
 - 7.2.1 ESD disturbances
 - 7.3 Display disturbance to external environment
 - 7.3.1 Ionizetic radiation
 - 7.3.2 EMI
- 8.0 Reliability
 - 8.1 Mean time between failures
- 9.0 Quality assurance requirements
 - 9.1 Acceptance test
- 10.0 Serviceability

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 3	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

1.0 Introduction

This document is related to the 17" AUTOSCAN color monitor
and max. resolution:
1920 X 1440 by 60Hz refresh rate

2.0 General description

This AUTOSCAN analog colour monitor is specified as a display peripheral within an IBM compatible PC.

The AUTOSCAN analog colour monitor is to operate at
H: 30 to 92.0 KHz V: 50 to 160 Hz
can be applied to all RGB analog computers within this scanning frequencies.

The AUTOSCAN analog colour monitor is intended to be a finished product, basically a display device mounted inside a plastic enclosure which provides the aesthetic, mechanical, ergonomic and safety requirements.

2.1 General condition

The unit will produce a usable image after switching-on, measurements are to be carried out with a full stabilized set after about 30 minutes warm-up at room ambient temperature of 25°C.
Repetitive power on/off cycles are allowed though should be avoided within 4 sec.

3.0 Electrical characteristics

3.1 Signal interface

This AUTOSCAN analog colour display has an analog video interface to operates at a multi-frequencies timing in several display modes.

3.1.1 Input requirements

A. Input signals

Video - 0.7 Vp-p 75 ohms (for individual of R,G and B signals must not deviate 0.015 Vp -p from each other for balance of white pattern)

Sync - TTL level
(between 0 and 0.6 V to be considered as low level, between 2.3 and 5.0 V as high level)

B. Impedance

Video - Terminated with 75 ohms
Sync - Terminated with 4.7K ohms pull-down resistors.

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 4	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

3.1.2 Signals input

The input video signals are applied to the display device through a video cable which is fixed to the monitor (flying cable length 1.5M).

Video input cable :
15 pin D-shell connector type with pin assignment as follows :

Pin assignment of 15P D-SUB connector

Pin No.	Assignment
P 1	Red video input
P 2	Green video input
P 3	Blue video input
P 4	Ground
P 5	GND
P 6	Red video ground
P 7	Green video ground
P 8	Blue video ground
P 9	Not connect
P10	Ground
P11	Ground
P12	Bi-directional data (SDA)
P13	H SYNC
P14	V SYNC
P15	DDC Data CLOCK (SCL)

3.1.3 Factory pre-set modes:

PRESET VIDEO RESOLUTION AND SYNC. POLARITIES

	Resolution modes	H. freq.	V. freq.	H.	V.
1.	640 x 350	31.5 Khz	70 HZ(VESA)	-	+
2.	640 x 400	31.5 Khz	70 HZ(VESA)	-	+
3.	640 x 480	43.2 Khz	85 HZ(VESA)	-	-
4.	800 x 600	46.9 Khz	75 HZ(VESA)	+	+
5.	800 x 600	53.7 Khz	85 HZ(VESA)	+	+
6.	1024 x 768	60.0 Khz	75 HZ(VESA)	+	+
7.	1024 x 768	68.7 Khz	85 HZ(VESA)	+	+
8.	1280 x 1024	80.0 Khz	75 Hz (VESA)	+	+
9.	1280 x 1024	91.1 Khz	85 Hz (VESA)	+	+

3 .2 Timing requirements

The pre-set timing table are shown as below
Timing Table : 1 - 9

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	5
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

TIMING FOR 107P2 17" FLAT AUTOSCAN COLOR MONITOR

REFERENCE PATTERN GENERATOR : CHROMA 2250

TABLE 1: 31.469 KHz/70Hz, 640 X 350, pixel=25.175 MHz

Horizontal			Vertical		
Frame border	=	0	Frame border	=	0
Total size	=	31.778 μ s	Total size	=	14.286 ms
Display size	=	25.422 μ s	Display size	=	11.122 ms
Rear porch	=	1.907 μ s	Rear porch	=	1.907 ms
Sync width	=	3.813 μ s	Sync width	=	0.064 ms
Sync polarity	=	-	Sync polarity	=	+

TABLE 2: 31.469 KHz/69.930Hz, 640 X 400, pixel=25.175 MHz

Horizontal			Vertical		
Frame border	=	0	Frame border	=	0
Total size	=	31.778 μ s	Total size	=	14.300 ms
Display size	=	25.422 μ s	Display size	=	12.711 ms
Rear porch	=	1.907 μ s	Rear porch	=	1.144 ms
Sync width	=	3.813 μ s	Sync width	=	0.064 ms
Sync polarity	=	-	Sync polarity	=	+

TABLE 3: 43.269 KHz/85.008Hz, 640 X 480, pixel=36.000 MHz

Horizontal			Vertical		
Frame border	=	0	Frame border	=	0
Total size	=	23.111 μ s	Total size	=	11.764 ms
Display size	=	17.778 μ s	Display size	=	11.093 ms
Rear porch	=	2.222 μ s	Rear porch	=	0.578 ms
Sync width	=	1.556 μ s	Sync width	=	0.069 ms
Sync polarity	=	-	Sync polarity	=	-

TABLE 4: 46.875KHz/75.000Hz, 800 X 600, pixel=49.500MHz

Horizontal			Vertical		
Frame border	=	0	Frame border	=	0
Total size	=	21.333 us	Total size	=	13.333 ms
Display size	=	16.162 us	Display size	=	12.800 ms
Rear porch	=	3.232 us	Rear porch	=	0.448 ms
Sync width	=	1.616 us	Sync width	=	0.064 ms
Sync polarity	=	+	Sync polarity	=	+

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	6
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

TABLE 5: 53.674KHz/85.061Hz, 800 X 600, pixel=56.250MHz

Horizontal		Vertical	
Frame border	= 0	Frame border	= 0
Total size	= 18.631 us	Total size	= 11.756 ms
Display size	= 14.222 us	Display size	= 11.179 ms
Rear porch	= 2.702 us	Rear porch	= 0.503 ms
Sync width	= 1.138 us	Sync width	= 0.056 ms
Sync polarity	= +	Sync polarity	= +

TABLE 6: 60.023KHz/75.029Hz, 1024 X 768, pixel=78.750MHz

Horizontal		Vertical	
Frame border	= 0	Frame border	= 0
Total size	= 16.660 us	Total size	= 13.328 ms
Display size	= 13.003 us	Display size	= 12.795 ms
Rear porch	= 2.235 us	Rear porch	= 0.466 ms
Sync width	= 1.219 us	Sync width	= 0.050 ms
Sync. polarity	= +	Sync. polarity	= +

TABLE 7: 68.677KHz/84.997Hz, 1024 X 768, pixel=94.500 MHz

Horizontal		Vertical	
Frame border	= 0	Frame border	= 0
Total size	= 14.561 us	Total size	= 11.765 ms
Display size	= 10.836 us	Display size	= 11.183 ms
Rear porch	= 2.201 us	Rear porch	= 0.524 ms
Sync width	= 1.016 us	Sync width	= 0.044 ms
Sync polarity	= +	Sync polarity	= +

TABLE 8: 79.976KHz/75.025Hz, 1280 X 1024, pixel=135.00MHz

Horizontal		Vertical	
Frame border	= 0	Frame border	= 0
Total size	= 12.504 us	Total size	= 13.329 ms
Display size	= 9.481 us	Display size	= 12.804 ms
Rear porch	= 1.837 us	Rear porch	= 0.475 ms
Sync width	= 1.067 us	Sync width	= 0.038 ms
Sync polarity	= +	Sync polarity	= +

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 7	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

PHILIPS



TABLE 9 :91.146 KHz/85.024Hz, 1280 X 1024, pixel=157.500 MHz

Horizontal		Vertical	
Frame border	= 0	Frame border	= 0
Total size	= 10.971 μs	Total size	= 11.761 ms
Display size	= 8.127 μs	Display size	= 11.234 ms
Rear porch	= 1.422 μs	Rear porch	= 0.483 ms
Sync width	= 1.016 μs	Sync width	= 0.033 ms
Sync polarity	= +	Sync polarity	= +

3.2.1 Horizontal scanning

Scanning frequency : 30 - 92.0 KHz,
H-shift range : 20 mm min.
Retrace time : Typical 2.30 us.

3.2.2 Vertical scanning

Scanning frequency : 50 - 160 Hz
V-shift range : 10 mm Min.

3.3 Power supply

The display device maintains the specified performance
in the range described as below :

Type	Mains current	Mains Voltage	Mains freq.
	1.8A max.	90 - 264 VAC	47-63Hz

Power consumption : 110 Watts Max.
Power cord length : 1.5M
Power cord type : 3 leads detachable power cord with
protective earth plug .

All rights strictly reserved. Reproduction or issue
to third parties in any form whatever is not permitted
without written authority from the proprietors. .

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 8	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

2838 100 05424



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

3.4 Power saving management system

MODE	SIGNAL			POWER	RECOVERY TIME
	H-SYNC	V-SYNC	VIDEO		
ON	ACTIVE	ACTIVE	ACTIVE	< 110W	NA
STAND-BY	INACTIVE	ACTIVE	BLANKED	< 15W	~ 3 SEC.
SUSPEND	ACTIVE	INACTIVE	BLANKED	< 15W	~ 3 SEC.
OFF	INACTIVE	INACTIVE	BLANKED	< 3W	~ 7 SEC

3.5 CRT Description

This display unit employs a high resolution CRT complying with the following specifications :

Type : M41LRY31X21
Dimensions : 17 inches
Super flat/square screen.
Pitch : 0.25mm dotted
Deflection angle : 90 degrees
Light transmission : 38%
Face treatment : AR film
Implosion protection : CRT is provided with P-mini-rim-band
EHT : 25 KV
Visible screen area : 325 mm x 244 mm

3.6 RGB Amplifier

3.6.1 Video amplifiers

Dot Rate : 202.5 MHz
Over / undershoot : 10% Max.
(Transient response)
Sag (background uniformity) : 5% Max. (pulses of 0.70H)

3.6.2 Brightness and contrast

Reference mode 68.7K/85Hz full white pattern at 9300K.

Brightness	Contrast	Light output (full white)
Minimum	Minimum	< 0.5 FL
Center	Maximum	31 +5 -3FL

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 9	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

3.7 Variation of image size

Due to brightness change
from 3 to 30 FL (Max.) : < 1.0 %

Due to aging
(0 to 40 °C) : < 1.0 %

Due to mains voltage
variation : < 1.0 %

3.8 Degaussing

An automatic degaussing circuit is provided which requires no intervention. The degaussing activated at the time of switch-on or switch-on again or pressing manual degaussing key after switch ing-off degaussing circuits for longer than 30 minutes.

3.9 Phosphor protection

The display device is sufficiently protected against the burning of phosphors in case of repetitive power cycling or absence of horizontal deflection.

3.10 Low emission requirements (MPRII, TCO95, TCO99)

Items	Band I ELF (rms)	Band II VLF (rms)
Alternating Electric Field	MPR-II ≤ 25 V/M TCO-95/99≤10	MPR-II ≤ 2.5V/M TCO-95/99≤1.0
Magnetic Field	MPR-II ≤ 250 nT TCO -95/99≤ 200 nT	MPR-II ≤ 25 nT TCO-95/99≤25 nT
E.S.P	≤ ± 500 V	

Band I : 5 to 2K Hz.
Band II : 2K to 400K Hz.
Test procedure according to Low emission test method.

3.11 Display data channel : DDC1/2B (VESA STANDARD)

The DDC HEX Data should be written into DDC memory inside the IC (7804 by EEPROM writer or equivalent method.

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 10	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

2838 100 05424

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

4.0 Display image (CRT facing east)

The monitor is aligned in a magnetic cage having the following magnetic field components :

Northern Hemisphere : H = 0, V = +0.43 ± 0.05G, Z = 0

Southern Hemisphere : H = 0, V = -0.52 ± 0.05G, Z = 0

Conditions for visual testing, unless otherwise stated:

- Input video signal - 700 mVp-p cross hatch
- Brightness control - 50%
- Contrast control - Adjusted to 31+5 -3FL of luminance with full white pattern

4.1 Display resolutions

See 3.1.3

4.2 Image size (Factory pre-set modes only)

The dimensions of guaranteed display area to be measured along the picture center of horizontal and vertical axis of the screen as listed below: (preset modes only, refer to fig. 1/fig 2)

Width : 306 +/- 3 mm ,(fig 1)

Height : 230 +/- 3 mm ,(fig 1)

4.3 Image centering deviation (Factory preset modes only)

With respect to fig. 2, the target relationships are the following :

IA - BI <= 5 mm IC - DI <=5 mm

Note : This centering is adjustable by the end-user.

4.4 Picture shift control range

- H-shift range : 20 mm min. (+/- 5mm,from center to each side)
- V-shift range : 10 mm min. (+/- 2mm,from center to each side)

4.5 Picture tilt

With respect to Fig. 3, Tilt to be measured on extremes of center line from bezel.

Tilt : <= 2 mm

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	11
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

2838 100 05424



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

4.6 Geometric distortions

It is acceptable that pincushion, trapezoid, rhomboid, rotation and various waves distortions must remain within the limits of tolerance as in fig. 4,

A , B	2.0mm
C , D	2.0mm

The waviness of any vertical or horizontal shall be less than 1.0 mm over a 50 mm distance.

4.7 Image non-linearity pattern with
10 equal blocks along horizontal axis,
8 equal blocks along vertical axis.

Overall : ≤ 5% (each horizontal and vertical)
 : ≤ 6 % (VGA)
Deviation of Two adjacent : ≤ 3 % (Adjacent block)
 : ≤ 3.5 % (VGA)

H. linearity = $\frac{X_{max.} - X_{min}}{X_{ma} x. + X_{min}}$ x 100%

V. linearity = $\frac{Y_{max.} - Y_{min}}{Y_{max.} + Y_{min}}$ x 100%

4.8 Mis-convergence

The maximum convergence error to be measured on a white spot or white display line to represents the maximum distance between the energy centers of any two primary colors. (See Fig. 6)
Mis-Convergence SPEC.

CRT Pitch	0.25mm
Zone A	0.15
Zone B	0.25
Zone C	0.35

4.9 Focus check (with 68.7K/85Hz,1024 x 768 mode)

Generate "@" characters (pattern as fig 7) to cover entire of the picture area (display size respect to fig. 1), adjust brightness control to 50% and contrast control to obtain 25 FL @ 5 -block pattern, the characters should be clearly identified in all display area.

4.10 Luminance uniformity

condition : With full white pattern, set contrast control at max. and adjust brightness control to get 30FL in center
the max. deviation to the rest of the s creen shall not exceed 25% of entire screen with any point.

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	12
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

4.11 White color adjustment

Based on the 1931 CIE chromaticity (colour triangle) diagram (x,y coordination).
coordination of white display on screen center should be:

for 9300 degreeK X = 0.283 +/- 0.015
 Y = 0.297 +/- 0.015
for 6500 degreeK X = 0.313 +/- 0.015
 Y = 0.329 +/- 0.015
for 5500 degreeK X = 0.332 +/- 0.015
 Y = 0.347 +/- 0.015

Check conditions :
Set brightness control at 50% position and contrast at maximum.

4.12 Color tracking on full white pattern

Ref. to white balance alignment result and set brightness at 50%, adjust contrast control from 5FL to max. position, the colour coordinate should not deviate more than following tolerance when compare to display center:

X= X nominal +/- 0.015
Y= Y nominal +/- 0.015

4.13 Purity

Test patterns : Full White / Red / Green / Blue.
Conditions:As stated in item 4.0, the purity must be checked under specific destinations of earth magnetic environments and the monitor to be well degaussed.
After warming -up time of 30 min., no coloured stains may occur in above four patterns.

4.14 Moire

Condition: Displaying a full white pattern , at any pre-set mode the display size of the set s to be set as stated in "Fig. 1".
Moire area should be less than 1/3 area @15FL via moire control.
However the OSD moire data of V-moire should have a default value (mode dependent) for product outgoing .Increasing the moire control value will have side effect on resolution (degrade focus),and phenomenon of flicker and sawtooth.

5.0 Mechanical characteristics

5.1 User controls (all at front) Right to left

- Power ON/OFF
- OSD Menu
- Up (Brightness)
- Down (Brightness)
- Right (Contrast)
- Left (Contrast)

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	13
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

- 6.0 Connectors and cables
 - 6.1.1 Power cord (plugable) type : Wall Plug ,non shielded and non-attached.
Length : 1.5 m +/- 50 mm . Plug curved at 90°.
 - 6.1.2 Signal cable
Length of video : 1.5 m +/- 50 mm flying in 15pins D-shell.

- 7.0 Environmental characteristics

The following sections to define the interference and susceptibility condition limits that might occur between external environment and the display device.

- 7.1 Susceptibility of display to external environment
 - 7.1.1 Operating limits
 - A). Temperature : 0 °C to 35°C
Humidity : 10 to 90% (W/O condensation)
Air pressure : 700 ~ 1100 mbar
 - B). Non-operating limits (storage)
Temper ature : -25°C to 65°C
Humidity : 10 to 90 % (W/O condensation)
Altitude : 300 to 1100 mbar

- 7.1.2 Transportation packages
 - A) Carton box (inside dimension)
: 496(W) x 520 (H) x 556 (D) mm.
 - B) Transportation conditions

(see table, shown as below)

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 14	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

B-1 Transportation standards

TEST	Standard reference	Philips severity		Remarks
Drop 1C-3E-6F	NSTA	Gross weight (Kg)	Drop height (cm)	*W/O 10% drop height increment
		20	61	
Random vibration		Truck spectrum, 0.73 Grms, 30 min/axis, 3 axes		
Shock (non-oper)		- 1/2 sine pulse: 100G<3ms, 6 shocks - Square pulse: 35G, 4.2mps, 6 shocks for screen size up to 15", 30G for ≥ 17" mointor. - Damage boundary curve: * CRT supplier spec. is used to define maximum acceptable CRT fragility.		Design stage only.

B-2 Container loading

Q'ty	Container size					
	40Feet		20Feet		High cube 40 Feet	
	W/Pallet		W/Pallet		W/Pallet	
	Yes	No	Yes	No	Yes	No
Layers	4	4	4	4	4	4
Sets per layer	4	4	4	4	4	4
Sets per block	16	16	16	16	16	16
Blocks per container	24	24	10	10	24	24
Total set	384	384	160	160	384	384

7.2 Display disturbances from external environment

7.2.1 ESD Disturbances

According to IEC65 (also refer to IEC801 -2 for detail).

7.3 Display disturbances to external environment

The disturbances induced by the display and tolerated by the environment are defined as follows :

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang		SUPERS.	23	590 — 15 10 A4
TY	CHECK	DATE	00-06-07		
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

7.3.1 Ionizetic radiation
Completely fulfilled International Commission of
Radio logical Protection (ICRP) requirement 0.5 mr/hrs.
Actually the set can reach 0.1 mr/hrs.

7.3.2 Safety and EMI requirements

Safety - (To be decided)

EMI - (To be decided)

EMS -(To be decided)

LOW EMISSION :TCO99

7.3.3 X-RAY radiation requirement /regulation

-USA/CANADA :DHHS 21 CFR, CHAPTER 1,SUBCHAPTER J
-GERMANY :RONTGEN VERORDNUNG ROV 1987.01.08

X-ray exposure at 5cm distance from any point of the external surface must not exceed
0.1 mR/H.

8.0 Reliabilit y

8.1 Mean time between failures
MTBF to be calculated according to Military standard
MIL -HDBK-217C.

MTBF >=75,000 Hours (Excluding CRT)

TOTAL HRS (POWER ON) X TOTAL SETS
PRACTICE of MTBF = -----
NBR. OF FAILED SETS

9.0 Quality assurance requirements

9.1 Acceptance test

According to MIL -STD-105D level II,
AQL : 0.65 (Major)
2.5 (Minor)

Customer acceptance :
criteria : UAW0377/00

10.0 Serviceability

The service ability of this monitor should fulfill the
requirements which are prescribed in UAW -0346 and
must be checked with the check list UAT -0361.

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	16
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.





FIG-1 IMAGE DIMENSION

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	17
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.



$|A-B| \text{ AND } |C-D| < 5 \text{ mm}$

FIG-2 IMAGE CENTERING

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590 — 18	10 A4
TY	CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.




FIG-3 IMAGE ROTATION

CLASS NO.		CM25-17" 107P2 92KHz AR CRT						
		TYPE : 107P20/00H				8639 000 10649		
		BRAND : PHILIPS						
00-06-07								
NAME	K.C. Huang		SUPERS.	23	590	19	10	A4
TY		CHECK	DATE	00-06-07	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.




FIG-4 IMAGE GEOMETRY

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	20
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.




FIG-5 CONTRAST AND BRIGHTNESS MEASUREMENT PATTERNS

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	21
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

2838 100 05424

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.




FIG-6 MISCONVERGENCE MEASUREMENT AREA


CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	22
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

2838 100 05424

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.



CHARACTER
FOR FOCUS
(CHROMA 2200/2250 CHR NO. 56)
FIG - 7

CLASS NO.		CM25-17" 107P2 92KHz AR CRT			
		TYPE : 107P20/00H		8639 000 10649	
		BRAND : PHILIPS			
00-06-07					
NAME	K.C. Huang	SUPERS.	23	590	23
TY		CHECK	DATE 00-06-07	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

2838 100 05424

◀◀ Go to cover page

Model :107P20/00H CM25-17"

ITEM	CODE	NUMBER	DESCRIPTION	ITEM	CODE	NUMBER	DESCRIPTION	
1050	3138	178	52451	107P2B-M SEMIFINISHED SET	2170	2020	552 90816	CERC DC 50V 4N7 PM10
1053	2438	070	98118	MAINS CORD	2172	2038	034 54229	ELCAP S 25V 22UF PM20 2E T
1054	3138	168	73391	I/F CABLE	2301	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1101	▲	2422	086 00208	FUSE T4AH 250V	2302	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1104		2422	132 07402	RELAY SDT -SS-112DM	2304	2238	861 15221	MLCC 0850 NPO 220PF J 4B 9
1106		2438	128 00183	SWITCH	2305	2238	861 15221	MLCC 0850 NPO 220PF J 4B 9
1111		3138	178 76762	AC INLET ASSY	2307	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1113		2438	025 00208	WAFER 2P	2308	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1151	▲	8238	274 38951	CRT 17"/.25P/NF/U1 M41LRY31X21	2309	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1152		3138	188 05041	107P2B-M ALL CHAS.KITS	2310	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1153		3322	144 89801	SPOILER	2311	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1155		3138	178 52461	107P2B-M MAIN PCB ASSY	2312	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1157		3138	178 50931	107P2B-M VIDEO PCB ASSY	2316	2238	861 15478	SMD 0805 NPO 4P7 50V 0.25P
1158		3138	178 52471	107P2B-M KEY CNTR PCB ASSY	2317	2238	861 15478	SMD 0805 NPO 4P7 50V 0.25P
1252		3138	178 50871	H-O/P TRANS ASSY-107P2A _{Asus}	2318	2238	861 15478	SMD 0805 NPO 4P7 50V 0.25P
1253		3138	178 05571	POWER TRA ASSY-24MAX(7105)	2319	2222	861 12479	MLCC 0805 NPO 50V 47P COL R
1255		3138	178 07621	vert ic assy - 107pgs3(7404)	2322	2222	910 16647	CER2 0805 X7R 25V 68N PM10
1258		3138	178 52481	EEPROM ASSY -107P2B (7804)	2323	2238	580 16627	CER2 0805 X7R 50V 10N PM10 R
1301		2438	031 00072	CON BM V 12P M 2.5 625/635 B	2324	2038	034 53221	ELCAP S 16V 220UF PM20 2E
1351		3138	128 67151	VIDEO IC ASSY-24HP17(7701)	2325	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1401		3138	100 20993	CONNECTOR 4P 2.35 DIA J101	2326	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1703		2438	025 00085	1P CONN. 2.35 DIA - J10	2341	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1711		2422	500 80064	CRT SCKT CVT3280 11P DIA 22.5	2342	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1712		3138	178 77651	1P WAFER 2.0 DIA	2343	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1713		3138	178 79621	CON BM H 10P M 2.5 625/626 B	2344	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1714		2438	031 00056	CON BM H 10P M 2.5 625/626 B	2345	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1800		2438	031 00167	CON BM IC V 42P F 1.778 DIL B	2346	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1800		2438	031 00167	CON BM IC V 42P F 1.778 DIL B	2347	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1801		2438	543 00061	RES XTL 12MHZ 30P HC49U B	2348	2038	034 56109	ELCAP S 50V 10UF PM20 2E
1802		2438	031 00063	CON BM V 4P M 2.5 625/635 B	2349	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1891		2438	128 00196	SWI TACT H EQU. TO 5 GY 160G	2350	2238	910 16649	MLCC 0805 X7R 25V 100N K R
1892		2438	128 00196	SWI TACT H EQU. TO 5 GY 160G	2408	2038	302 50218	MEF CAP 10N 100V PM2 2E
1893		2438	128 00196	SWI TACT H EQU. TO 5 GY 160G	2409	2020	552 90798	CERC DC 50V 220P PM10
1894		2438	128 00196	SWI TACT H EQU. TO 5 GY 160G	2410	2020	552 90807	CERC DC 50V 1N0 PM10
1895		2438	128 00196	SWI TACT H EQU. TO 5 GY 160G	2411	2038	034 56228	ELCAP S 50V 2UF2 PM20 2E T
2101		2020	307 90006	ACROSS LINE CAP 250V 1UF PM20	2412	2020	552 90816	CERC DC 50V 4N7 PM10
2102		2020	554 90139	CERSAF NSB 250V S 4N7 PM20 B	2413	2038	034 53101	ELCAP S 16V 100UF PM20 2E
2103		2020	554 90139	CERSAF NSB 250V S 4N7 PM20 B	2414	2038	034 56109	ELCAP S 50V 10UF PM20 2E
2105		2038	035 00315	ELCAP LZK 400V S 220U PM20 B	2415	2038	034 58229	ELCAP S 100V 22UF PM20 2E T
2109		2038	034 56109	ELCAP S 50V 10UF PM20 2E	2416	2020	552 90834	CCAP DC 50V 22N Z A
2111		2038	302 50229	CAP MPOL 250V S 10N PM5 A	2417	2038	034 56228	ELCAP S 50V 2UF2 PM20 2E T
2112		2038	034 56228	ELCAP S 50V 2UF2 PM20 2E T	2418	2020	552 90816	CERC DC 50V 4N7 PM10
2114	▲	2020	554 90138	CERSAF NSA 250V S 4N7 PM20 B	2419	2020	552 90834	CCAP DC 50V 22N Z A
2115		2038	034 54229	ELCAP S 25V 22UF PM20 2E T	2422	2038	031 45471	ELCAP 470UF 25V PM20 2E 105C T
2120		2038	554 00065	CER2 DC Y5V 50V S 100N PM8020	2423	2038	031 45471	ELCAP 470UF 25V PM20 2E 105C T
2122		2020	552 90812	CERC CAP 50V 2N2 PM10	2424	2038	302 50095	MEF CAP 100V 100N PM10 2E
2123		2020	552 90812	CERC CAP 50V 2N2 PM10	2425	2038	302 50125	MEF CAP 100V 220N PM10 2E
2128		2252	602 14416	CERC CAP DC 2KV 470P PM10 X7R	2426	2038	034 58229	ELCAP S 100V 22UF PM20 2E T
2152		2038	031 92479	ELCAP 160V 47UF PM20 105DEG C	2501	2020	552 90598	CERC DC NPO 50V 47P PM5 2
2154		2038	035 00026	ELCAP S 100V 220UF PM20 3	2502	2038	302 00162	PP CAP 330N 250V PM10 6E
2156		2038	031 35102	ELCAP S 16V 1000UF PM20 2E T	2503	2020	552 90598	CERC DC NPO 50V 47P PM5 2
2157		2038	031 35102	ELCAP S 16V 1000UF PM20 2E T	2504	2020	552 90598	CERC DC NPO 50V 47P PM5 2
2160		2038	031 35102	ELCAP S 16V 1000UF PM20 2E T	2505	2038	034 53102	ELCAP S 16V 1000UF PM20 T
2161		2020	552 90834	CCAP DC 50V 22N Z A	2506	2038	302 50212	POLCAP 100V 100N PM5 2E T
2162		2038	034 54229	ELCAP S 25V 22UF PM20 2E T	2507	2038	301 50186	PPN 100V 8N2 PM5 T
2163		2038	302 50212	POLCAP 100V 100N PM5 2E T	2508	2038	302 50218	MEF CAP 10N 100V PM2 2E
2164		2252	608 08011	CERC DC X7R 500V S 100P PM10 A	2509	2038	301 50157	CAP PP PPN 100V S 5N6 PM2 A
2165		2038	035 00056	ELCAP 2200UF 16V SX PM20	2510	2038	034 56108	ELCAP S 50V 1UF PM20 2E T
2166		2038	034 53471	ELCAP VX 470UF M 16V 2E 10x12.5 T	2511	2020	552 90598	CERC DC NPO 50V 47P PM5 2
2167		2252	608 08221	CER2 DC X7R 500V S 2N2 PM10 A	2512	2038	034 56109	ELCAP S 50V 10UF PM20 2E

ITEM	CODE NUMBER			DESCRIPTION	ITEM	CODE NUMBER			DESCRIPTION	
2513	2038	302	50095	MEF CAP 100V 100N PM10 2E	2724	2038	031	85108	ELCAP S 100V 1UF PM20 2E T	
2514	2038	301	50189	CAP PP PPN 100V S 2N2 PM2	2725	2422	549	44346	SPARK GAP DSP-201m	
2515	2038	302	50125	MEF CAP 100V 220N PM10 2E	2726	2222	580	15649	CER2 0805 X7R 50V 100N PM10 R	
2516	2038	302	50212	POLCAP 100V 100N PM5 2E T	2731	2038	035	22801	ECAP NP 1U 160V 105C NK	
2517	2020	552	90807	CERC DC 50V 1N0 PM10	2732	2038	031	85108	ELCAP S 100V 1UF PM20 2E T	
2518	2020	552	90598	CERC DC NPO 50V 47P PM5 2	2733	2422	549	44346	SPARK GAP DSP-201m	
2519	2020	552	90798	CERC DC 50V 220P PM10	2751	2038	035	22801	ECAP NP 1U 160V 105C NK	
2520	2020	552	90798	CERC DC 50V 220P PM10	2752	2038	031	85108	ELCAP S 100V 1UF PM20 2E T	
2521	2038	031	65109	ELCAP VT 50V 10UF PM20 2E	2753	2422	549	44346	SPARK GAP DSP-201m	
2523	2252	608	08221	CER2 DC X7R 500V S 2N2 PM10 A	2760	2238	861	15471	CMC 0805 NPO 470P 50V J	
2526	2038	554	00065	CER2 DC Y5V 50V S 100N PM8020	2761	2238	910	16649	MLCC 0805 X7R 25V 100N K R	
2527	2020	552	90807	CERC DC 50V 1N0 PM10	2762	2235	559	00099	CERC CAP 2KV 10N PM10 4E	
2601	2020	552	90834	CCAP DC 50V 22N Z A	2763	2238	580	16623	MLCC 0805 X7R 4N7F K 4B 9	
2602	2038	302	50099	POLCAP 100V 470N PM10 2E	2771	2238	910	16649	MLCC 0805 X7R 25V 100N K R	
2603	2038	035	22801	ECAP NP 1U 160V 105C NK	2772	2252	608	08021	CERC DC X7R 500V 1N0 PM10 A	
2604	2038	031	92003	ELCAP S 250V 33UF PM20 2E	2773	2038	034	56109	ELCAP S 50V 10UF PM20 2E	
2605	2038	302	50229	CAP MPOL 250V S 10N PM5 A	2776	2038	031	85479	ELCAP VT 100V S 47U PM20 B	
2606	2038	302	00162	PP CAP 330N 250V PM10 6E	2777	2238	910	16649	MLCC 0805 X7R 25V 100N K R	
2607	2038	031	45101	ECAP S 25V 100UF M 2E T	2778	2038	031	45479	ELCAP VT 25V 47UF PM20 2E T	
2608	2038	031	45101	ECAP S 25V 100UF M 2E T	2779	2020	552	90598	CERC DC NPO 50V 47P PM5 2	
2609	2252	608	08221	CER2 DC X7R 500V S 2N2 PM10 A	2780	2020	552	90598	CERC DC NPO 50V 47P PM5 2	
2610	2252	602	14216	CERCAP DC 2KV 220P K X7R T	2781	2222	861	12479	MLCC 0805 NPO 50V 47P COL R	
2611	2252	602	14216	CERCAP DC 2KV 220P K X7R T	2782	2222	861	12479	MLCC 0805 NPO 50V 47P COL R	
2612	2252	608	08221	CER2 DC X7R 500V S 2N2 PM10 A	2783	2038	031	45479	ELCAP VT 25V 47UF PM20 2E T	
2613	2038	301	00119	PPS CAP 1K6V 4N7 PM5	2785	2038	031	45479	ELCAP VT 25V 47UF PM20 2E T	
2614	2038	302	50125	MEF CAP 100V 220N PM10 2E	2801	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2618	2038	302	50212	POLCAP 100V 100N PM5 2E T	2802	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2619	2252	602	14416	CERC CAP DC 2KV 470P PM10 X7R	2803	2020	552	90589	CERC DC NPO 50V 10P PM5 2E T	
2620	2020	552	90834	CCAP DC 50V 22N Z A	2804	2020	552	90589	CERC DC NPO 50V 10P PM5 2E T	
2621	2020	552	90834	CCAP DC 50V 22N Z A	2805	2020	552	90798	CERC DC 50V 220P PM10	
2622	2038	301	00208	CAP PP PPN 250V S 47N PM5 B	2806	2020	552	90598	CERC DC NPO 50V 47P PM5 2	
2623	2038	301	00224	MPS CAP 220N 250V PM5 7E	2807	2020	552	90598	CERC DC NPO 50V 47P PM5 2	
2624	2038	301	00414	MPS CAP 200N 250V PM5 7E	2808	2038	554	00065	CER2 DC Y5V 50V S 100N PM8020	
2625	2038	301	00333	MPS CAP 910N 250V PM5 7E	2809	2020	552	90598	CERC DC NPO 50V 47P PM5 2	
2626	2038	301	00303	MPS CAP 470N 250V PM5 7E	2810	2020	552	90598	CERC DC NPO 50V 47P PM5 2	
2627	2038	302	50095	MEF CAP 100V 100N PM10 2E	2811	2020	552	90834	CCAP DC 50V 22N Z A	
2628	2020	552	90834	CCAP DC 50V 22N Z A	2812	2020	552	90834	CCAP DC 50V 22N Z A	
2640	2038	031	65109	ELCAP VT 50V 10UF PM20 2E	2814	2038	034	56109	ELCAP S 50V 10UF PM20 2E	
2641	2038	031	65109	ELCAP VT 50V 10UF PM20 2E	2816	2020	552	90598	CERC DC NPO 50V 47P PM5 2	
2645	2020	552	90834	CCAP DC 50V 22N Z A	2819	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2646	2038	302	50212	POLCAP 100V 100N PM5 2E T	2820	2038	034	53471	ELCAP VX 470UF M 16V 2E 10x12.5 T	
2651	2038	301	00307	MPS CAP 120N 250V PM5 7E	2821	2038	034	56109	ELCAP S 50V 10UF PM20 2E	
2652	2020	552	90834	CCAP DC 50V 22N Z A	2822	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2653	2020	552	90812	CERC CAP 50V 2N2 PM10	2823	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2654	2038	035	00026	ELCAP S 100V 220UF PM20 3	2824	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2655	2038	301	00109	PPN CAP 3N3 630V PM10	2825	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2656	2038	302	00102	MEF CAP 400V 47N PM10 6E	2826	2038	034	56228	ELCAP S 50V 2UF2 PM20 2E T	
2657	2222	347	41473	POLCAP S 250V 47N PM10 6E	2831	2020	552	90816	CERC DC 50V 4N7 PM10	
2658	2038	302	00209	MEF CAP 1U 100V 6E	2832	2020	552	90816	CERC DC 50V 4N7 PM10	
2659	2038	302	50099	POLCAP 100V 470N PM10 2E	2833	2038	034	53101	ELCAP S 16V 100UF PM20 2E	
2660	2038	031	95007	ELCAP VT 10U M 250V 2E T 10x20	3101	2322	242	13684	METGLAZ RST A VTR 37 680K PM5	
2661	2038	034	56108	ELCAP S 50V 1UF PM20 2E T	3102	2322	662	96758	DEGAUSSING PTC THERMISTOR B	
2665	2038	034	56109	ELCAP S 50V 10UF PM20 2E	3104	⚠	2322	205	33109	RST FUSE NFR25 10R PM5
2666	2252	608	08221	CER2 DC X7R 500V S 2N2 PM10 A	3105	2138	116	13304	RST MFLM MF50S A 330K PM1 A	
2667	2252	602	14216	CERCAP DC 2KV 220P K X7R T	3106	2138	116	13304	RST MFLM MF50S A 330K PM1 A	
2668	2252	602	08116	CER2 DC X7R 2KV S 150P PM10 A	3107	⚠	2322	205	33221	RST FUSE NFR25 S 220R PM5
2702	2238	910	16649	MLCC 0805 X7R 25V 100N K R	3108	⚠	2322	205	33221	RST FUSE NFR25 S 220R PM5
2721	2038	031	85109	ELCAP S 100V 10UF PM20 2E T	3109	2138	660	00038	SCK -055 NTC	
2722	2222	580	15649	CER2 0805 X7R 50V 100N PM10 R	3111	2120	105	92452	RST MOX 3W RSS S 27K PM5 B	
2723	2038	035	22801	ECAP NP 1U 160V 105C NK	3112	2138	105	00111	PWR RES 820R 5W	

Parts list

[◀ Go to cover page](#)

ITEM	CODE	NUMBER	DESCRIPTION	ITEM	CODE	NUMBER	DESCRIPTION
3113 ▲	2322	205	33109 RST FUSE NFR25 10R PM5	3328	2322	730	61562 RES 5.6K RC-11 SMD 0805 T
3114	2138	101	13103 RST CRB CR12 A 10K PM5 A	3329	2322	730	61562 RES 5.6K RC-11 SMD 0805 T
3115	2138	112	73477 CARBRST R25 0.47R PM5	3330	2322	730	61394 SMD R0805 390K PM5
3116	2138	112	73477 CARBRST R25 0.47R PM5	3332	2138	101	13101 RST CRB CR12 A 100R PM5 A
3117	2138	112	73477 CARBRST R25 0.47R PM5	3333	2138	101	13101 RST CRB CR12 A 100R PM5 A
3119 ▲	2322	205	33221 RST FUSE NFR25 S 220R PM5	3334	2322	730	61151 RST SM 0805 RC11 150R PM5 R
3120	2138	112	73477 CARBRST R25 0.47R PM5	3335	2322	730	61102 RST SMC 0805 RC11 1K PM5 T
3121	2322	242	13475 METGLAZ RST A VR37 4M7 PM5 T	3336	2322	730	61102 RST SMC 0805 RC11 1K PM5 T
3122	2322	242	13475 METGLAZ RST A VR37 4M7 PM5 T	3337	2322	730	61102 RST SMC 0805 RC11 1K PM5 T
3123	2138	101	13333 RST CRB CR12 A 33K PM5 A	3338	2322	730	61472 RST SM 0805 RC11 4K7 PM5 R
3124	2138	101	13334 RST CRB CR12 A 330K PM5 A	3339	2322	730	61472 RST SM 0805 RC11 4K7 PM5 R
3125	2138	101	13102 RST CRB CR12 A 1K PM5 A	3341	2322	730	61101 RST SM 0805 RC11 100R PM5 R
3126	2138	101	13152 RST CRB CR12 A 1K5 PM5 A	3342	2322	730	61101 RST SM 0805 RC11 100R PM5 R
3127 ▲	2322	205	33221 RST FUSE NFR25 S 220R PM5	3343	2322	730	61101 RST SM 0805 RC11 100R PM5 R
3128	2138	101	13229 RST CRB CR12 A 22R PM5 A	3344	2138	101	13101 RST CRB CR12 A 100R PM5 A
3129	2138	101	13101 RST CRB CR12 A 100R PM5 A	3345	2138	101	13101 RST CRB CR12 A 100R PM5 A
3130	2138	101	13333 RST CRB CR12 A 33K PM5 A	3346	2138	101	13101 RST CRB CR12 A 100R PM5 A
3131	2138	116	12403 RST MFLM MF50S A 24K PM1 A	3347	2322	730	61101 RST SM 0805 RC11 100R PM5 R
3132 ▲	2322	205	33109 RST FUSE NFR25 10R PM5	3348	2322	730	61101 RST SM 0805 RC11 100R PM5 R
3133	2138	101	13821 RST CRB CR12 A 820R PM5 A	3349	2138	101	13101 RST CRB CR12 A 100R PM5 A
3134	2138	101	13822 RST CRB CR12 A 8K2 PM5 A	3350	2322	730	61101 RST SM 0805 RC11 100R PM5 R
3135	2138	101	13102 RST CRB CR12 A 1K PM5 A	3351	2138	101	13101 RST CRB CR12 A 100R PM5 A
3139	2138	101	13103 RST CRB CR12 A 10K PM5 A	3352	2138	101	00369 CABON RES. CR-12 1/6W 0 OHM
3151	2138	116	17503 RST MFLM MF50S A 75K PM1 A	3353	2138	101	00369 CABON RES. CR-12 1/6W 0 OHM
3153	2138	116	12202 RST MFLM MF50S A 2K2 PM1 A	3354	2138	101	00369 CABON RES. CR-12 1/6W 0 OHM
3154	2138	116	17503 RST MFLM MF50S A 75K PM1 A	3359	2138	101	00369 CABON RES. CR-12 1/6W 0 OHM
3156	2138	101	13333 RST CRB CR12 A 33K PM5 A	3360	2322	730	91002 RST SM 0805 JUMP. MAX 0R05 T
3158	2138	116	11502 RST MFLM MF50S A 1K5 PM1 A	3361	2322	730	91002 RST SM 0805 JUMP. MAX 0R05 T
3159	2138	116	11504 RST MFLM MF50S A 150K PM1 A	3362	2322	730	61228 RES 2R2 SMD 0805
3160	2138	105	00061 RST MOX 2W RSS S 15K PM5	3363	2322	730	61228 RES 2R2 SMD 0805
3161	2138	101	13102 RST CRB CR12 A 1K PM5 A	3372	2322	730	91002 RST SM 0805 JUMP. MAX 0R05 T
3162	2138	101	13102 RST CRB CR12 A 1K PM5 A	3376	2322	730	91002 RST SM 0805 JUMP. MAX 0R05 T
3163	2138	116	13902 RST MFLM MF50S A 3K9 PM1 A	3378	2322	730	91002 RST SM 0805 JUMP. MAX 0R05 T
3164	2138	116	15601 RST MFLM MF50S A 560R PM1 A	3379	2322	730	91002 RST SM 0805 JUMP. MAX 0R05 T
3165	2138	365	00061 RTRM CER LIN 500R H VG068TL1 B	3380	2322	730	91002 RST SM 0805 JUMP. MAX 0R05 T
3166	2138	101	13333 RST CRB CR12 A 33K PM5 A	3401	2138	116	12202 RST MFLM MF50S A 2K2 PM1 A
3167	2138	101	13102 RST CRB CR12 A 1K PM5 A	3402	2138	101	13471 RST CRB CR12 A 470R PM5 A
3168	2138	101	13472 RST CRB CR12 A 4K7 PM5 A	3403	2138	101	13471 RST CRB CR12 A 470R PM5 A
3170	2138	101	13101 RST CRB CR12 A 100R PM5 A	3404	2138	116	12202 RST MFLM MF50S A 2K2 PM1 A
3171	2138	101	13102 RST CRB CR12 A 1K PM5 A	3405 ▲	2322	207	33108 MET FLM RST NFR25H 1R0 PM5 T
3172	2138	116	11504 RST MFLM MF50S A 150K PM1 A	3406	2138	116	04188 RST MFLM MF50S A 1R8 PM5 A
3173	2138	101	13102 RST CRB CR12 A 1K PM5 A	3407	2138	101	13479 RST CRB CR12 A 47R PM5 A
3301	2322	734	67509 RST SM 0805 RC11 75R PM1 T	3408	2138	116	04188 RST MFLM MF50S A 1R8 PM5 A
3302	2322	734	67509 RST SM 0805 RC11 75R PM1 T	3409 ▲	2322	205	33221 RST FUSE NFR25 S 220R PM5
3303	2322	734	67509 RST SM 0805 RC11 75R PM1 T	3410	2138	116	04158 RST MFLM MF50S A 1R5 PM5 A
3305	2322	730	61472 RST SM 0805 RC11 4K7 PM5 R	3411 ▲	2322	207	33101 RST MFLM NFR25H 100R PM5
3306	2322	730	61472 RST SM 0805 RC11 4K7 PM5 R	3413	2138	101	13223 RST CRB CR12 A 22K PM5 A
3307	2322	730	61101 RST SM 0805 RC11 100R PM5 R	3414	2138	101	13822 RST CRB CR12 A 8K2 PM5 A
3309	2322	730	61102 RST SMC 0805 RC11 1K PM5 T	3415	2138	101	13101 RST CRB CR12 A 100R PM5 A
3310	2138	101	13102 RST CRB CR12 A 1K PM5 A	3416	2138	101	13102 RST CRB CR12 A 1K PM5 A
3311	2322	730	61102 RST SMC 0805 RC11 1K PM5 T	3417	2138	101	13472 RST CRB CR12 A 4K7 PM5 A
3312	2322	730	61479 RES 47R 0805 SMD RC-11 T	3418	2138	101	13103 RST CRB CR12 A 10K PM5 A
3313	2322	730	61479 RES 47R 0805 SMD RC-11 T	3419	2138	101	13473 RST CRB CR12 A 47K PM5 A
3314	2322	730	61479 RES 47R 0805 SMD RC-11 T	3420	2138	101	13473 RST CRB CR12 A 47K PM5 A
3315	2322	730	61222 RST SM 0805 RC11 2K2 PM5 R	3421	2138	101	13331 RST CRB CR12 A 330R PM5 A
3316	2322	730	61101 RST SM 0805 RC11 100R PM5 R	3422	2138	101	13479 RST CRB CR12 A 47R PM5 A
3324	2322	730	61332 RES 3K3 0805 SMD	3423	2138	101	13473 RST CRB CR12 A 47K PM5 A
3325	2138	101	13103 RST CRB CR12 A 10K PM5 A	3424	2138	101	13154 RST CRB CR12 A 150K PM5 A
3326	2322	730	61103 RES 10K RC-11 SMD 0805 T	3425	2138	101	13334 RST CRB CR12 A 330K PM5 A
3327	2322	730	61562 RES 5.6K RC-11 SMD 0805 T	3427	2138	101	13472 RST CRB CR12 A 4K7 PM5 A

ITEM	CODE	NUMBER	DESCRIPTION	ITEM	CODE	NUMBER	DESCRIPTION
3428	2138	101 13152	RST CRB CR12 A 1K5 PM5 A	3614	2322	207 33108	MET FLM RST NFR25H 1R0 PM5 T
3429	2138	101 13103	RST CRB CR12 A 10K PM5 A	3616	2138	101 13103	RST CRB CR12 A 10K PM5 A
3431	2322	207 33108	MET FLM RST NFR25H 1R0 PM5 T	3617	2138	101 13681	RST CRB CR12 A 680R PM5 A
3432	2138	101 13479	RST CRB CR12 A 47R PM5 A	3618	2138	116 15602	RST MFLM MF50S A 5K6 PM1 A
3456	2322	205 33109	RST FUSE NFR25 10R PM5	3621	2138	101 13229	RST CRB CR12 A 22R PM5 A
3501	2138	116 12202	RST MFLM MF50S A 2K2 PM1 A	3622	2138	101 13473	RST CRB CR12 A 47K PM5 A
3502	2138	101 13103	RST CRB CR12 A 10K PM5 A	3623	2138	101 13105	RST CRB CR12 A 1M PM5 A
3503	2138	101 13223	RST CRB CR12 A 22K PM5 A	3624	2138	101 13562	RST CRB CR12 A 5K6 PM5 A
3504	2138	116 12403	RST MFLM MF50S A 24K PM1 A	3626	2138	101 13229	RST CRB CR12 A 22R PM5 A
3505	2138	101 13103	RST CRB CR12 A 10K PM5 A	3627	2120	105 92388	METOX FLM RST 2W 33R PM5
3506	2138	101 13103	RST CRB CR12 A 10K PM5 A	3628	2138	116 04188	RST MFLM MF50S A 1R8 PM5 A
3507	2138	101 13471	RST CRB CR12 A 470R PM5 A	3629	2138	101 13333	RST CRB CR12 A 33K PM5 A
3508	2138	116 12403	RST MFLM MF50S A 24K PM1 A	3630	2138	116 15601	RST MFLM MF50S A 560R PM1 A
3509	2138	101 13102	RST CRB CR12 A 1K PM5 A	3631	2138	105 00093	RES RSH-7W/150 OHM
3510	2138	116 13304	RST MFLM MF50S A 330K PM1 A	3632	2138	101 13682	RST CRB CR12 A 6K8 PM5 A
3511	2138	101 13472	RST CRB CR12 A 4K7 PM5 A	3633	2138	101 13682	RST CRB CR12 A 6K8 PM5 A
3513	2138	101 13473	RST CRB CR12 A 47K PM5 A	3634	2138	101 13103	RST CRB CR12 A 10K PM5 A
3514	2138	101 13331	RST CRB CR12 A 330R PM5 A	3635	2138	101 13103	RST CRB CR12 A 10K PM5 A
3515	2138	116 15601	RST MFLM MF50S A 560R PM1 A	3636	2138	101 13473	RST CRB CR12 A 47K PM5 A
3516	2138	101 13472	RST CRB CR12 A 4K7 PM5 A	3637	2138	101 13473	RST CRB CR12 A 47K PM5 A
3517	2138	101 13333	RST CRB CR12 A 33K PM5 A	3638	2138	101 13154	RST CRB CR12 A 150K PM5 A
3518	2138	101 13222	RST CRB CR12 A 2K2 PM5 A	3639	2138	101 13154	RST CRB CR12 A 150K PM5 A
3519	2138	101 13682	RST CRB CR12 A 6K8 PM5 A	3640	2138	101 13154	RST CRB CR12 A 150K PM5 A
3520	2138	101 13103	RST CRB CR12 A 10K PM5 A	3641	2138	101 13154	RST CRB CR12 A 150K PM5 A
3521	2138	116 17503	RST MFLM MF50S A 75K PM1 A	3642	2138	101 13473	RST CRB CR12 A 47K PM5 A
3522	2138	101 13101	RST CRB CR12 A 100R PM5 A	3643	2138	101 13473	RST CRB CR12 A 47K PM5 A
3523	2138	116 12702	RST MFLM MF50S A 2K7 PM1 A	3644	2138	101 13103	RST CRB CR12 A 10K PM5 A
3524	2138	116 17321	RST MFLM MF50S A 732R PM1 A	3645	2138	101 13103	RST CRB CR12 A 10K PM5 A
3525	2138	101 13332	RST CRB CR12 A 3K3 PM5 A	3646	2138	101 13682	RST CRB CR12 A 6K8 PM5 A
3526	2138	101 13154	RST CRB CR12 A 150K PM5 A	3647	2138	101 13682	RST CRB CR12 A 6K8 PM5 A
3527	2138	101 13101	RST CRB CR12 A 100R PM5 A	3648	2138	101 13471	RST CRB CR12 A 470R PM5 A
3528	2138	101 13101	RST CRB CR12 A 100R PM5 A	3649	2322	205 33109	RST FUSE NFR25 10R PM5
3529	2138	101 13101	RST CRB CR12 A 100R PM5 A	3652	2322	242 13224	METGLAZ RST A VR37 220K PM5 T
3530	2138	101 13101	RST CRB CR12 A 100R PM5 A	3653	2138	116 15601	RST MFLM MF50S A 560R PM1 A
3531	2138	101 13101	RST CRB CR12 A 100R PM5 A	3654	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3532	2138	116 17503	RST MFLM MF50S A 75K PM1 A	3655	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3533	2138	116 17503	RST MFLM MF50S A 75K PM1 A	3656	2138	101 13101	RST CRB CR12 A 100R PM5 A
3534	2138	101 13154	RST CRB CR12 A 150K PM5 A	3658	2138	101 13229	RST CRB CR12 A 22R PM5 A
3535	2138	101 13123	RST CRB CR12 A 12K PM5 A	3659	2322	205 33109	RST FUSE NFR25 10R PM5
3536	2138	101 13154	RST CRB CR12 A 150K PM5 A	3660	2138	101 13152	RST CRB CR12 A 1K5 PM5 A
3537	2138	101 13224	RST CRB CR12 A 220K PM5 A	3661	2138	101 13123	RST CRB CR12 A 12K PM5 A
3538	2138	365 00087	RTRM CER V 100K VG067TH1 B	3662	2138	116 14704	RST MFLM MF50S A 470K PM1 A
3540	2322	207 33228	RST FUSE NFR25H 2R2 PM5	3663	2120	101 28222	RST CMP ERC12 A 2K2 PM10 A
3541	2322	207 33228	RST FUSE NFR25H 2R2 PM5	3664	2322	242 13224	METGLAZ RST A VR37 220K PM5 T
3542	2322	207 33108	MET FLM RST NFR25H 1R0 PM5 T	3665	2322	242 13224	METGLAZ RST A VR37 220K PM5 T
3543	2138	101 13105	RST CRB CR12 A 1M PM5 A	3666	2138	116 04475	RST MFLM MF50S A 4M7 PM5
3597	2138	116 11005	RST MFLM MF50S A 1M PM1 A	3667	2138	116 17503	RST MFLM MF50S A 75K PM1 A
3599	2138	116 17503	RST MFLM MF50S A 75K PM1 A	3668	2138	101 13681	RST CRB CR12 A 680R PM5 A
3601	2138	101 13101	RST CRB CR12 A 100R PM5 A	3669	2138	101 13333	RST CRB CR12 A 33K PM5 A
3602	2138	101 13103	RST CRB CR12 A 10K PM5 A	3670	2138	101 13223	RST CRB CR12 A 22K PM5 A
3603	2322	205 33479	MET FLM RST NFR25 47R PM5PM5 T	3671	2138	101 13152	RST CRB CR12 A 1K5 PM5 A
3604	2120	105 92191	METOX FLM RST 5K6 3W PM5 T	3672	2138	101 13101	RST CRB CR12 A 100R PM5 A
3605	2138	105 00119	RST MOX 5W RSS S 1R2 PM5 B	3673	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3606	2322	205 33109	RST FUSE NFR25 10R PM5	3674	2138	101 13333	RST CRB CR12 A 33K PM5 A
3607	2322	207 33101	RST MFLM NFR25H 100R PM5	3675	2138	101 13103	RST CRB CR12 A 10K PM5 A
3608	2138	101 13223	RST CRB CR12 A 22K PM5 A	3676	2138	101 13334	RST CRB CR12 A 330K PM5 A
3609	2322	207 33101	RST MFLM NFR25H 100R PM5	3677	2138	101 13229	RST CRB CR12 A 22R PM5 A
3610	2138	105 00095	RST MOX 7W RSH S 33R PM5	3678	2138	101 13224	RST CRB CR12 A 220K PM5 A
3612	2138	101 13681	RST CRB CR12 A 680R PM5 A	3679	2138	101 13682	RST CRB CR12 A 6K8 PM5 A
3613	2322	207 33108	MET FLM RST NFR25H 1R0 PM5 T	3680	2138	101 13335	RST CRB CR12 A 3M3 PM5 A

Parts list

 Go to cover page

ITEM	CODE	NUMBER	DESCRIPTION	ITEM	CODE	NUMBER	DESCRIPTION
3681	2120	105 92392	MET FLM RST 1W 47R PM5 RSS B	3763	2322	730 61332	RES 3K3 0805 SMD
3682	2138	116 12202	RST MFLM MF50S A 2K2 PM1 A	3764	2322	730 61472	RST SM 0805 RC11 4K7 PM5 R
3684	2138	101 13333	RST CRB CR12 A 33K PM5 A	3765	2322	730 61682	RES 6K8 0805 SMD
3685	2138	101 13154	RST CRB CR12 A 150K PM5 A	3767	2322	730 61472	RST SM 0805 RC11 4K7 PM5 R
3686	2138	101 13333	RST CRB CR12 A 33K PM5 A	3771	2120	101 28152	CARBRST COMP 1/2W 1K5 PM10
3687	2138	105 00094	RES RSH 7W 510R PM5	3772	2120	101 28153	CARBRST COMP 1/2W 15K PM10
3690	2322	242 13106	METGLAZ RST A VR37 10M PM5	3773	2138	116 11802	RST MFLM MF50S A 1K8 PM1 A
3691	2138	101 13473	RST CRB CR12 A 47K PM5 A	3775	2138	112 73479	CARBRST FLM CR25 47R PM5
3692	2138	101 13103	RST CRB CR12 A 10K PM5 A	3776	2322	730 61101	RST SM 0805 RC11 100R PM5 R
3693	2138	101 13154	RST CRB CR12 A 150K PM5 A	3777	2322	730 61101	RST SM 0805 RC11 100R PM5 R
3694	2138	101 13229	RST CRB CR12 A 22R PM5 A	3778	2322	730 61102	RST SMC 0805 RC11 1K PM5 T
3695	2322	242 13106	METGLAZ RST A VR37 10M PM5	3779	2138	112 73271	CARBRST FLM CR25 270R PM5
3696	2138	101 13105	RST CRB CR12 A 1M PM5 A	3781	2138	101 13332	RST CRB CR12 A 3K3 PM5 A
3697	2322	205 33109	RST FUSE NFR25 10R PM5	3784	2138	101 00369	CABON RES. CR-12 1/6W 0 OHM
3698	2138	365 00084	RTRM CER LIN 20K V VG067TH1 B	3785	2138	101 00369	CABON RES. CR-12 1/6W 0 OHM
3703	2138	101 13339	RST CRB CR12 A 33R PM5 A	3801	2138	101 13101	RST CRB CR12 A 100R PM5 A
3704	2138	101 13471	RST CRB CR12 A 470R PM5 A	3803	2138	101 13101	RST CRB CR12 A 100R PM5 A
3705	2138	101 13471	RST CRB CR12 A 470R PM5 A	3804	2138	101 13101	RST CRB CR12 A 100R PM5 A
3706	2138	101 13471	RST CRB CR12 A 470R PM5 A	3805	2138	101 13101	RST CRB CR12 A 100R PM5 A
3707	2322	730 61101	RST SM 0805 RC11 100R PM5 R	3806	2138	101 13101	RST CRB CR12 A 100R PM5 A
3713	2138	101 13339	RST CRB CR12 A 33R PM5 A	3807	2138	101 13101	RST CRB CR12 A 100R PM5 A
3716	2138	101 13339	RST CRB CR12 A 33R PM5 A	3809	2138	101 13101	RST CRB CR12 A 100R PM5 A
3718	2138	101 13479	RST CRB CR12 A 47R PM5 A	3810	2138	101 13332	RST CRB CR12 A 3K3 PM5 A
3719	2138	101 13479	RST CRB CR12 A 47R PM5 A	3811	2138	101 13103	RST CRB CR12 A 10K PM5 A
3720	2138	101 13479	RST CRB CR12 A 47R PM5 A	3812	2138	101 13103	RST CRB CR12 A 10K PM5 A
3721	2120	101 28479	CARBRST COMP 1/2W 47R PM10	3813	2138	101 13101	RST CRB CR12 A 100R PM5 A
3722	2138	112 73224	CARBRST FLM CR25 220K PM5	3815	2138	101 13101	RST CRB CR12 A 100R PM5 A
3723	2138	101 13821	RST CRB CR12 A 820R PM5 A	3816	2138	101 13101	RST CRB CR12 A 100R PM5 A
3724	2138	116 11503	RST MFLM MF50S A 15K PM1 A	3817	2138	101 13103	RST CRB CR12 A 10K PM5 A
3725	2322	730 61274	SMD R0805 270K PM5 R	3818	2138	116 13303	RST MFLM MF50S A 33K PM1 A
3726	2138	112 73683	CARBRST FLM CR25 68K PM5	3819	2138	112 03007	RES ARRAY 4K7 9A
3727	2138	101 13303	RST CRB CR12 A 30K PM5 A	3820	2138	101 13103	RST CRB CR12 A 10K PM5 A
3728	2138	112 73109	CARBRST FLM CR25 10R PM5	3821	2138	101 13103	RST CRB CR12 A 10K PM5 A
3729	2138	101 13479	RST CRB CR12 A 47R PM5 A	3823	2138	101 13331	RST CRB CR12 A 330R PM5 A
3730	2322	730 61105	RES 1M RC-11 SMD 0805 T	3824	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3731	2120	101 28479	CARBRST COMP 1/2W 47R PM10	3825	2138	101 13103	RST CRB CR12 A 10K PM5 A
3732	2138	112 73224	CARBRST FLM CR25 220K PM5	3826	2138	101 13331	RST CRB CR12 A 330R PM5 A
3733	2138	101 13821	RST CRB CR12 A 820R PM5 A	3828	2138	101 13103	RST CRB CR12 A 10K PM5 A
3734	2138	116 11503	RST MFLM MF50S A 15K PM1 A	3829	2138	101 13332	RST CRB CR12 A 3K3 PM5 A
3735	2322	730 61274	SMD R0805 270K PM5 R	3830	2138	101 13103	RST CRB CR12 A 10K PM5 A
3736	2138	112 73683	CARBRST FLM CR25 68K PM5	3831	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3737	2138	101 13303	RST CRB CR12 A 30K PM5 A	3832	2138	101 13123	RST CRB CR12 A 12K PM5 A
3738	2138	112 73109	CARBRST FLM CR25 10R PM5	3833	2138	101 13103	RST CRB CR12 A 10K PM5 A
3740	2322	730 91002	RST SM 0805 JUMP. MAX 0R05 T	3834	2138	101 13103	RST CRB CR12 A 10K PM5 A
3741	2322	730 61105	RES 1M RC-11 SMD 0805 T	3835	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3742	2322	730 61105	RES 1M RC-11 SMD 0805 T	3836	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3743	2322	730 61759	RST SM 0805 RC11 75R PM5 T	3837	2138	101 13123	RST CRB CR12 A 12K PM5 A
3744	2322	730 61759	RST SM 0805 RC11 75R PM5 T	3839	2138	101 13101	RST CRB CR12 A 100R PM5 A
3745	2322	730 61759	RST SM 0805 RC11 75R PM5 T	3840	2138	101 13101	RST CRB CR12 A 100R PM5 A
3751	2120	101 28479	CARBRST COMP 1/2W 47R PM10	3841	2138	101 13102	RST CRB CR12 A 1K PM5 A
3752	2138	112 73224	CARBRST FLM CR25 220K PM5	3842	2138	101 13102	RST CRB CR12 A 1K PM5 A
3753	2138	101 13821	RST CRB CR12 A 820R PM5 A	3843	2138	101 13102	RST CRB CR12 A 1K PM5 A
3754	2138	116 11503	RST MFLM MF50S A 15K PM1 A	3844	2138	101 13102	RST CRB CR12 A 1K PM5 A
3755	2322	730 61274	SMD R0805 270K PM5 R	3845	2138	101 13102	RST CRB CR12 A 1K PM5 A
3756	2138	112 73683	CARBRST FLM CR25 68K PM5	3856	2138	101 13101	RST CRB CR12 A 100R PM5 A
3757	2138	101 13303	RST CRB CR12 A 30K PM5 A	3857	2138	101 13101	RST CRB CR12 A 100R PM5 A
3758	2138	112 73109	CARBRST FLM CR25 10R PM5	3858	2138	101 13101	RST CRB CR12 A 100R PM5 A
3760	2138	116 13001	RST MFLM MF50S A 300R PM1 A	3861	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3761	2322	730 61102	RST SMC 0805 RC11 1K PM5 T	3862	2138	101 13472	RST CRB CR12 A 4K7 PM5 A
3762	2322	730 61103	RES 10K RC-11 SMD 0805 T	3863	2138	101 13472	RST CRB CR12 A 4K7 PM5 A

ITEM	CODE	NUMBER	DESCRIPTION	ITEM	CODE	NUMBER	DESCRIPTION
3871	2138	101 13473	RST CRB CR12 A 47K PM5 A	6125	3198	010 10011	DIODE 1N4148 (UAW)
3872	2138	101 13103	RST CRB CR12 A 10K PM5 A	6148	9335	435 00133	DIO REC BYV27-100
3873	2138	101 13564	RST CRB CR12 A 560K PM5 A	6151	9338	185 20133	DIO REC BYM26E A(PHSE) A
3874	2138	101 13223	RST CRB CR12 A 22K PM5 A	6152	9338	185 00133	DIODE BYM26C
3875	2138	101 13103	RST CRB CR12 A 10K PM5 A	6153	9335	435 00133	DIO REC BYV27-100
3876	2138	101 13564	RST CRB CR12 A 560K PM5 A	6154	3198	010 10071	DIODE BAV21 (UAW)
3877	2138	101 13223	RST CRB CR12 A 22K PM5 A	6155	9335	435 00133	DIO REC BYV27-100
3878	2138	101 13473	RST CRB CR12 A 47K PM5 A	6157	9334	979 50683	DIODE RGP10J (GI)
3879	2120	105 92137	MET FLM RST 1W 150R PM5 5E	6158	3198	010 10071	DIODE BAV21 (UAW)
3880	2138	101 13222	RST CRB CR12 A 2K2 PM5 A	6159	3198	010 10011	DIODE 1N4148 (UAW)
3881	2138	101 13222	RST CRB CR12 A 2K2 PM5 A	6161	3198	010 10011	DIODE 1N4148 (UAW)
3882	2120	105 92137	MET FLM RST 1W 150R PM5 5E	6162	3198	010 21291	DIODE BZX79-C12 (UAW)
3891	2138	116 11004	RST MFLM MF50S A 100K PM1 A	6163	3198	010 10011	DIODE 1N4148 (UAW)
3892	2138	116 15603	RST MFLM MF50S A 56K PM1 A	6164	3198	010 10071	DIODE BAV21 (UAW)
3893	2138	116 14702	RST MFLM MF50S A 4K7 PM1 A	6165	3198	010 21591	DIODE BZX79-C15 (UAW)
3894	2138	116 11503	RST MFLM MF50S A 15K PM1 A	6166	3198	010 10011	DIODE 1N4148 (UAW)
3895	2138	116 12403	RST MFLM MF50S A 24K PM1 A	6301	3198	010 25681	DIODE BZX79-C5V6 (UAW)
5007	3138	168 75602	DEGAUSSING COIL	6302	3198	010 25681	DIODE BZX79-C5V6 (UAW)
5101	3138	178 72231	POWER TRANSFORMER	6303	3198	010 25681	DIODE BZX79-C5V6 (UAW)
5102	3138	178 70891	LINE FILTER 15 mH MIN.	6304	3198	010 25681	DIODE BZX79-C5V6 (UAW)
5106	3138	178 79161	BAR COIL 7U5H PM10	6405	9337	516 60683	DIODE RGP10D (GI)
5107	3138	178 79161	BAR COIL 7U5H PM10	6421	3198	010 10011	DIODE 1N4148 (UAW)
5112	2438	535 98026	IND FXD BEAD EMI 100MHZ 35R R	6422	3198	010 10011	DIODE 1N4148 (UAW)
5151	2422	535 94971	DRUM CHOKE COIL 100UH T	6423	3198	010 10011	DIODE 1N4148 (UAW)
5152	2422	535 94971	DRUM CHOKE COIL 100UH T	6424	3198	010 10011	DIODE 1N4148 (UAW)
5153	2422	535 94971	DRUM CHOKE COIL 100UH T	6425	3198	010 10011	DIODE 1N4148 (UAW)
5155	2422	535 94971	DRUM CHOKE COIL 100UH T	6426	3198	010 21591	DIODE BZX79-C15 (UAW)
5156	2422	535 94971	DRUM CHOKE COIL 100UH T	6427	3198	010 23391	DIODE BZX79-C33
5301	2422	535 97608	COIL 1MUH8 PM10	6428	3198	010 10011	DIODE 1N4148 (UAW)
5303	2438	535 98026	IND FXD BEAD EMI 100MHZ 35R R	6430	9337	516 60683	DIODE RGP10D (GI)
5601	3138	178 71331	DRIVER TRANSF.	6501	3198	010 10011	DIODE 1N4148 (UAW)
5602	3138	178 71732	DRUM COIL 20MH	6502	3198	010 10011	DIODE 1N4148 (UAW)
5603	3138	168 75481	CENTERING TRANSFORMER	6503	3198	010 10011	DIODE 1N4148 (UAW)
5604	3138	178 75991	DRUM CHOKE COIL 6MH	6505	3198	010 10071	DIODE BAV21 (UAW)
5606	3138	178 77891	LINEARITY COIL 1.6UH	6507	3198	010 21291	DIODE BZX79-C12 (UAW)
5608	2438	535 98025	IND FXD BEAD EMI 100MHZ 60R R	6508	3198	010 10011	DIODE 1N4148 (UAW)
5610	2438	535 98026	IND FXD BEAD EMI 100MHZ 35R R	6509	3198	010 10011	DIODE 1N4148 (UAW)
5611	3138	178 77501	DAF TRANSFORMER	6510	3198	010 10011	DIODE 1N4148 (UAW)
5612	3138	168 77551	LOT	6511	3198	010 10011	DIODE 1N4148 (UAW)
5613	2422	535 94971	DRUM CHOKE COIL 100UH T	6601	9339	577 60683	DIODE SB140 (GI)
5701	2422	535 97608	COIL 1MUH8 PM10	6602	9340	312 20127	DIO REC BY459-1500 S (ELCO) L
5702	2422	535 97608	COIL 1MUH8 PM10	6603	3198	010 21591	DIODE BZX79-C15 (UAW)
5721	3138	178 77951	COIL 0.33UH PM10	6604	9322	115 74682	DIODE 31DF4
5732	3138	178 77951	COIL 0.33UH PM10	6605	9337	516 60683	DIODE RGP10D (GI)
5752	3138	178 77951	COIL 0.33UH PM10	6606	9337	516 60683	DIODE RGP10D (GI)
5771	3138	108 74951	BAR COIL 5UH PM10	6609	3198	010 24781	DIODE BZX79-C4V7 (UAW)
5779	2422	535 97608	COIL 1MUH8 PM10	6611	9334	979 50683	DIODE RGP10J (GI)
5781	2422	535 94971	DRUM CHOKE COIL 100UH T	6621	9322	126 36682	DIODE 31DF6 6E
5786	2422	535 97608	COIL 1MUH8 PM10	6624	3198	010 21291	DIODE BZX79-C12 (UAW)
5801	2422	535 97416	COIL 33MUH PM10	6627	3198	010 10011	DIODE 1N4148 (UAW)
6102	9319	002 63671	BRIDGE GBU6J	6630	9334	979 50683	DIODE RGP10J (GI)
6103	9334	979 50683	DIODE RGP10J (GI)	6633	3198	010 10011	DIODE 1N4148 (UAW)
6106	3198	010 10011	DIODE 1N4148 (UAW)	6634	9334	979 50683	DIODE RGP10J (GI)
6107	3198	010 10071	DIODE BAV21 (UAW)	6711	3198	010 25181	DIODE BZX79-C5V1 (UAW)
6108	9334	979 50683	DIODE RGP10J (GI)	6721	3198	010 10531	SMD DIODE BAV103
6109	9337	516 60683	DIODE RGP10D (GI)	6722	3198	010 10071	DIODE BAV21 (UAW)
6113	3198	010 10011	DIODE 1N4148 (UAW)	6724	3198	010 10531	SMD DIODE BAV103
6116	3198	010 27591	DIODE BZX79-C75(UAW)	6731	3198	010 10531	SMD DIODE BAV103
6121	3198	010 10011	DIODE 1N4148 (UAW)	6732	3198	010 10071	DIODE BAV21 (UAW)
6124	3198	010 10011	DIODE 1N4148 (UAW)	6734	3198	010 10531	SMD DIODE BAV103

Parts list

 Go to cover page

ITEM	CODE NUMBER			DESCRIPTION	ITEM	CODE NUMBER			DESCRIPTION
6751	3198	010	10071	DIODE BAV21 (UAW)	7636	3198	020	40041	TRANS BC547C (UAW)
6752	3198	010	10071	DIODE BAV21 (UAW)	7640	3198	020	43311	TRANS PH2369 (UAW)
6754	3198	010	10531	SMD DIODE BAV103	7641	3198	020	40161	TRANS BC558C (UAW)
6771	9334	939	60683	DIODE RGP10G (GI)	7642	9340	258	70126	TRA SIG MPSA44
6801	3198	010	10011	DIODE 1N4148 (UAW)	7701	9322	112	34687	IC LM2405T 11P
6802	3198	010	10011	DIODE 1N4148 (UAW)	7702	9336	056	80678	IC LM317LZRP 3P
6804	3198	010	10011	DIODE 1N4148 (UAW)	7721	3198	020	43011	TRANS BF422 (UAW)
6875	9322	146	03682	LED L-3WYGW	7722	3198	020	43011	TRANS BF422 (UAW)
7102	3198	020	43591	TRANS. BC338-40	7731	3198	020	43011	TRANS BF422 (UAW)
7103	▲ 9322	140	14667	PHOTOCOUPLER TCET1103G 4P	7732	3198	020	43011	TRANS BF422 (UAW)
7105	9322	092	42687	FET POW 2SK 1940-01	7751	3198	020	43011	TRANS BF422 (UAW)
7106	9352	645	03112	IC TEA1504AP/N2 14P	7752	3198	020	43011	TRANS BF422 (UAW)
7113	9337	711	00686	IC TL431CLPRP 3P	7761	3198	020	40081	TRANS BC548C (UAW)
7152	9335	282	90682	IC MC7808CT 3P	7801	8238	274	39361	IC 6148-K420PH-01A
7153	9334	536	00682	IC MC7805CT 3P	7801	8238	274	38741	CPU IC WT62P2 42P
7154	9338	268	50126	TRANS BT169B T	7801	8238	274	39361	IC 6148-K420PH-01A
7155	3198	020	43011	TRANS BF422 (UAW)	7801	8238	274	38741	CPU IC WT62P2 42P
7156	3198	020	40041	TRANS BC547C (UAW)	7803	3198	020	40161	TRANS BC558C (UAW)
7157	3198	020	40041	TRANS BC547C (UAW)	7804	9322	126	62682	IC M24C16-BN6 8P
7158	3198	020	43491	TRANS BC328-40	7805	3198	020	40041	TRANS BC547C (UAW)
7159	3198	020	40041	TRANS BC547C (UAW)	7811	9352	628	49112	IC TDA7073A/N4 16P
7301	9352	616	28112	IC TDA4886A/V1 24P	601	3138	117	02631	E-D.F.U. ASSY-V/E
7302	9352	674	03112	VE IC TDA 4822	602	3138	117	02641	E-D.F.U.-V/E
7303	9322	106	11676	IC LE33CZ-AP 3P	178	3138	105	40011	SETTING UP GUIDE
7304	8238	274	34421	OSD IC MTV018-27					
7322	3198	020	40081	TRANS BC548C (UAW)	450	3138	106	58651	CARTON
7404	9322	144	36687	IC TDA8177F 7P	451	3138	106	56841	CUSHION - TOP
7410	9322	019	59682	IC UC3843AN	453	3138	106	56852	CUSHION - BTM
7411	3198	020	40041	TRANS BC547C (UAW)	454	3138	106	56651	PE BAG
7412	3198	020	40041	TRANS BC547C (UAW)					
7413	3198	020	40041	TRANS BC547C (UAW)	139	3138	104	50701	SPONGE
7414	3198	020	40041	TRANS BC547C (UAW)	44	3138	104	48612	BASE
7501	3198	020	40041	TRANS BC547C (UAW)	53	3138	104	48602	SWIVEL
7502	3198	020	43021	TRANS BF423 (UAW)	60	3138	104	49481	FOOT RUBBER
7503	9352	637	56112	IC TDA4841PS-V2 32P	153	3138	106	58051	P.E. BAG-E-D.F.U.
7504	9332	377	80126	TRANS BC546B (UAW)					
7505	3198	020	40161	TRANS BC558C (UAW)	1	3138	127	50141	FRONT CABINET ASSY
7507	3198	020	40041	TRANS BC547C (UAW)	2	3138	107	97181	BACK COVER ASSY
7601	9340	039	60126	TRANS BSN254A	3	3138	107	98401	PEDESTAL ASSY
7602	9340	263	00127	TRANS POW BU2527AF					
7603	3198	020	43591	TRANS. BC338-40	42	3138	127	50151	KNOB ASSY
7604	3198	020	43491	TRANS BC328-40	46	3138	104	49891	KNOB-OSD
7605	9322	110	31687	FET POW MTP5P25 (MOTAO L)	47	3138	104	53791	KNOB-POWER
7606	9332	514	50127	TRANS BD330	48	3138	104	50672	LENS-POWER
7607	9332	514	40127	TRANS BD329	127	3138	101	32302	SPRING-POWER
7608	3198	020	43011	TRANS BF422 (UAW)	78	3138	101	66847	BOTTON PLATE
7609	9332	514	40127	TRANS BD329					
7610	3198	020	40161	TRANS BC558C (UAW)	1	3138	103	53561	VIDEO PCB - MULTI
7611	9333	935	10602	IC LM358N 8P (PHILIPS)	1	3138	103	53541	MAIN BOARD-CM25 107P GSIII
7612	3198	020	40041	TRANS BC547C (UAW)	1	3138	103	53032	MULIT BOARD-KEY CNTR. (24GS3 10
7613	3198	020	40041	TRANS BC547C (UAW)					
7615	9322	145	62667	TRAN SLA5058	56	3138	103	22571	STANDOFF
7618	3198	020	40041	TRANS BC547C (UAW)	64	3138	104	36221	RUBBER SUPPORT
7619	3198	020	40041	TRANS BC547C (UAW)	102	3138	103	21851	CABLE TIE
7621	9322	054	09687	TRAN.MOS MTP6N60	50	3138	104	51071	SWITCH CAP - 107P
7622	9337	739	70687	MOSFET IRF640					
7626	3198	020	43591	TRANS. BC338-40					
7627	3198	020	43491	TRANS BC328-40					
7629	3198	020	40041	TRANS BC547C (UAW)					
7630	3198	020	40041	TRANS BC547C (UAW)					


Recommended Parts List

Go to cover page

Model : 107P20/00H CM25-17” GS 3

ITEM	CODE	NUMBER	DESCRIPT
1	3138	127 50141	FRONT CABINET ASSY
2	3138	107 97181	BACK COVER ASSY
3	3138	107 98401	PEDESTAL ASSY
44	3138	104 48612	BASE
53	3138	104 48602	SWIVEL
42	3138	127 50151	KNOB ASSY
46	3138	104 49891	KNOB-OSD
47	3138	104 53791	KNOB-POWER
450	3138	106 58651	CARTON
451	3138	106 56841	CUSHION - TOP
453	3138	106 56852	CUSHION - BTM
454	3138	106 56651	PE BAG
153	3138	106 58051	P.E. BAG-E-D.F.U.
601	3138	117 02631	E-D.F.U. ASSY-V/E
602	3138	117 02641	E-D.F.U.-V/E
178	3138	105 40011	SETTING UP GUIDE
1053	2438	070 98118	MAINS CORD
1054	3138	168 73391	I/F CABLE
1101	2422	086 00208	FUSE T4AH 250V
1155	3138	178 52461	107P2B-M MAIN PCB ASSY
1157	3138	178 50931	107P2B-M VIDEO PCB ASSY
1158	3138	178 52471	107P2B-M KEY CNTR PCB ASSY
1258	3138	178 52481	EEPROM ASSY -107P2B (7804)
5101	3138	178 72231	POWER TRANSFORMER
5612	3138	168 77551	LOT
7301	9352	616 28112	IC TDA4886A/V1 24P
7304	8238	274 34421	OSD IC MTV018-27
7302	9352	674 03112	VE IC TDA 4822
7303	9322	106 11676	IC LE33CZ-AP 3P
7410	9322	019 59682	IC UC3843AN
7103	9322	140 14667	PHOTOCOUPLER TCET1103G 4P
7113	9337	711 00686	IC TL431CLPRP 3P
7105	9322	092 42687	FET POW 2SK 1940-01
7154	9338	268 50126	TRANS BT169B T
7404	9322	144 36687	IC TDA8177F 7P
7503	9352	637 56112	IC TDA4841PS-V2 32P
7605	9322	110 31687	FET POW MTP5P25 (MOTAO L)
7621	9322	054 09687	TRAN.MOS MTP6N60
7622	9337	739 70687	MOSFET IRF640
7801	8238	274 39361	IC 6148-K420PH-01A(mask)

Exploded View



0. Warning

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the unit via a wrist wrap with resistance. Keep components and tools also at the same potential !

1. Servicing of SMDs (Surface Mounted Devices)


1.1 General cautions on handling and storage

- Oxidation on the terminals of SMDs results in poor soldering. Do not handle SMDs with bare hands.
- Avoid using storage places that are sensitive to oxidation such as places with sulphur or chlorine gas, direct sunlight, high temperatures or a high degree of humidity. The capacitance or resistance value of the SMDs may be affected by this.
- Rough handling of circuit boards containing SMDs may cause damage to the components as well as the circuit boards. Circuit boards containing SMDs should never be bent or flexed. Different circuit board materials expand and contract at different rates when heated or cooled and the components and/or solder connections may be damaged due to the stress. Never rub or scrape chip components as this may cause the value of the component to change. Similarly, do not slide the circuit board across any surface.

1.2 Removal of SMDs

- Heat the solder (for 2-3 seconds) at each terminal of the chip. By means of litz wire and a slight horizontal force, small components can be removed with the soldering iron. They can also be removed with a solder sucker (see Fig. 1A)

Fig. 1 DISMOUNTING



- While holding the SMD with a pair of tweezers, take it off gently using the soldering iron's heat applied to each terminal (see Fig. 1 B).
- Remove the excess solder on the solder lands by means of litz wire or a solder sucker (see Fig. 1C).

1.3 Caution on removal

- When handling the soldering iron, use suitable pressure and be careful.
- When removing the chip, do not use undue force with the pair of tweezers.
- The soldering iron to be used (approx. 30 W) should


preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).

- The chip, once removed, must never be reused.

1.4 Attachment of SMDs

- Locate the SMD on the solder lands by means of tweezers and solder the component on one side. Ensure that the component is positioned correctly on the solder lands (see Fig. 2A).
- Next complete the soldering of the terminals of the component (see Fig. 2B).


Fig. 2 MOUNTING




2. Caution when attaching SMDs


- When soldering the SMD terminals, do not touch them directly with the soldering iron. The soldering should be done as quickly as possible, care must be taken to avoid damage to the terminals of the SMDs themselves.
- Keep the SMD's body in contact with the printed board when soldering.
- The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).
- Soldering should not be done outside the solder land.
- Soldering flux (of rosin) may be used, but should not be acidic.
- After soldering, let the SMD cool down gradually at room temperature.
- The quantity of solder must be proportional to the size of the solder land. If the quantity is too great, the SMD might crack or the solder lands might be torn loose from the printed board (see Fig. 3).

Fig. 3 Examples





Waveform C




B3




H-Voltage Schematic Diagram


[Go to cover page](#)

B2




Waveform B






Click for Main Panel C.B.A. (HMC)



Click here for Main Panel(B,C) C.B.A. (CUS)


1101 G1	2505 D8	2666 A6	3154 E2	3524 C9	3651 A7	3826 G9	6103 G4	7106 G5	9119 E5	9828 E9
1102 G8	2506 C8	2667 A6	3156 E5	3525 C8	3652 A6	3827 E9	6106 G5	7113 F5	9120 E2	9829 F7
1104 E1	2507 C9	2668 A6	3158 F6	3526 C7	3653 D2	3828 E7	6107 G5	7152 E5	9121 D3	9830 E8
1106 G8	2508 C9	2669 A7	3159 F6	3527 D8	3654 D2	3829 E7	6108 G4	7153 F6	9122 D5	9831 E8
1111 F1	2509 C9	2801 D6	3160 E3	3528 C8	3655 D2	3830 F7	6109 F3	7154 E2	9123 F4	9832 E8
1113 G1	2510 E6	2802 D7	3161 E2	3529 C8	3656 B1	3831 F8	6113 E1	7155 E2	9124 D4	9833 E8
1115 F5	2511 D9	2803 E7	3162 E5	3530 C7	3658 A8	3832 F8	6116 F4	7156 F5	9125 D7	9837 D5
1401 B5	2512 D9	2804 E7	3163 F6	3531 C7	3659 C1	3833 F7	6121 F6	7157 F5	9126 D3	9838 E9
1602 A4	2513 D9	2805 E9	3164 F6	3532 E5	3660 A1	3834 F9	6124 F6	7158 E5	9131 E6	9840 E9
1603 B7	2514 C9	2806 F9	3165 F6	3533 D7	3661 A1	3835 F9	6125 F6	7159 F6	9132 F6	9841 E6
1604 B7	2515 C8	2807 F9	3166 E2	3534 C8	3662 A1	3836 F9	6148 E4	7404 C6	9133 D4	
1801 E7	2516 C8	2808 F7	3167 F5	3535 D9	3663 A2	3837 F8	6149 E3	7410 B1	9134 D2	
1802 E9	2517 D7	2809 F7	3168 E5	3536 C9	3664 A1	3838 F9	6151 E3	7411 D1	9135 D3	
1803 E9	2518 D8	2810 F7	3170 F5	3537 D9	3665 A6	3839 F9	6152 E3	7412 D1	9136 D3	
1812 B9	2519 C8	2811 F8	3171 F5	3538 A3	3666 B6	3840 F9	6153 E4	7413 C1	9137 D4	
1813 B9	2520 D8	2812 F8	3172 F5	3540 B5	3667 A6	3841 A9	6154 E5	7414 C1	9138 D3	
1814 C9	2521 E6	2813 E9	3173 F5	3541 C5	3668 B7	3842 A9	6155 E4	7501 E6	9140 E5	
1815 D9	2523 D5	2814 E7	3401 C7	3542 D8	3669 A1	3843 A9	6156 D4	7502 E6	9141 E6	
1816 A9	2526 C8	2815 E9	3402 C7	3543 D7	3670 B7	3844 A9	6157 E2	7503 C8	9142 E5	
2101 F2	2527 D9	2816 F7	3403 C7	3586 C4	3671 B8	3845 A9	6158 E6	7504 D5	9144 E5	
2102 F2	2528 D8	2819 D7	3404 C6	3597 A2	3672 A5	3851 B9	6159 E2	7505 D9	9145 D2	
2103 E2	2601 A5	2820 E6	3405 C6	3599 A2	3673 A1	3852 B9	6161 E2	7507 C7	9146 E5	
2104 G1	2602 A5	2821 F9	3406 B6	3601 A6	3674 A1	3853 B9	6162 F5	7601 A5	9152 D1	
2105 F2	2603 A6	2822 F7	3407 B5	3602 A5	3675 A1	3854 C9	6163 E2	7602 B4	9141 D1	
2109 G5	2604 D3	2823 F7	3408 C7	3603 C6	3676 A1	3855 D9	6164 E6	7603 D8	9146 B6	
2111 G4	2605 D4	2824 F6	3409 B6	3604 A5	3677 B8	3856 F7	6165 F5	7604 D8	9147 B6	
2112 G5	2606 C4	2825 F6	3410 B6	3605 B4	3678 A1	3857 F7	6166 E2	7605 C3	9148 B6	
2114 F3	2607 C5	2826 F6	3411 D6	3606 B3	3679 A9	3858 F7	6405 C6	7606 B5	9149 B6	
2115 D1	2608 B5	2831 E1	3413 C1	3607 D5	3680 B7	3861 E7	6421 A1	7607 C6	9142 B7	
2120 G6	2609 D5	2832 E1	3414 B1	3608 D3	3681 C7	3862 E7	6422 D1	7608 D6	9512 D8	
2122 G5	2610 C4	2833 D1	3415 C1	3609 C4	3682 B7	3863 E7	6423 C1	7609 B6	9513 D6	
2123 G5	2611 C4	3101 F1	3416 C1	3610 C5	3684 C7	3871 D1	6424 B1	7610 D6	9514 C8	
2128 G3	2612 D5	3102 G1	3417 D1	3612 C5	3685 B7	3872 E1	6425 B1	7611 B7	9515 D7	
2150 E3	2613 B3	3104 G4	3418 D1	3613 C4	3686 C7	3873 E1	6426 C1	7612 B9	9516 D7	
2152 D3	2614 B3	3105 G4	3419 C1	3614 D4	3687 A6	3874 E1	6427 C1	7613 A9	9517 D7	
2154 E3	2615 B4	3106 G4	3420 D1	3615 D4	3688 A3	3875 E1	6428 C1	7615 A8	9518 D7	
2156 E4	2616 B3	3107 G3	3421 D1	3616 D6	3689 A4	3876 E1	6430 C1	7618 A9	9520 D5	
2157 E4	2617 A4	3108 G2	3422 C1	3617 D6	3690 A2	3877 E1	6501 D9	7619 A9	9521 C7	
2160 E4	2618 B5	3109 G2	3423 A1	3618 C6	3691 A9	3878 E1	6502 C7	7621 C2	9522 C8	
2161 E5	2619 A5	3110 G2	3424 B1	3619 D4	3692 B9	3879 D1	6503 C7	7622 C2	9524 D9	
2162 E6	2620 B9	3111 G4	3425 C1	3620 D3	3693 B8	3880 D1	6504 C8	7626 B7	9525 D5	
2163 E2	2621 A9	3112 G3	3427 B1	3621 B8	3694 A8	3881 D1	6505 D5	7627 B7	9529 D8	
2164 E2	2622 B8	3113 F4	3428 B1	3622 B7	3695 A2	3882 E1	6507 D4	7629 B9	9612 A6	
2165 D2	2623 A8	3114 G5	3429 A1	3623 B6	3696 A3	4101 F4	6508 C9	7630 B8	9614 A6	
2166 F6	2624 A7	3115 G3	3431 C6	3624 B6	3697 B3	4102 E5	6509 D9	7631 D3	9615 C4	
2167 F6	2625 B8	3116 G3	3432 A1	3625 A3	3698 A3	4401 B6	6510 E7	7636 A9	9616 D5	
2170 F5	2626 A8	3117 G3	3456 D1	3626 A8	3801 E9	4601 A9	6511 C7	7640 D2	9617 D5	
2172 E5	2627 B7	3118 F3	3501 D5	3627 B6	3802 E9	4602 D1	6601 A4	7641 A1	9618 D5	
2407 C6	2628 A9	3119 G5	3502 E6	3628 B6	3803 E9	5101 F4	6603 D3	7642 B7	9619 A6	
2408 B1	2629 C4	3120 G3	3503 D6	3629 B6	3804 F8	5102 F1	6604 C3	7801 E7	9620 B7	
2409 C6	2630 B8	3121 G6	3504 D5	3630 B6	3805 F8	5106 G2	6605 B5	7802 F9	9621 A6	
2410 B1	2631 B8	3122 G6	3505 D5	3631 A5	3806 F8	5107 G2	6606 C6	7803 F8	9622 C3	
2411 B1	2632 A8	3123 F5	3506 E6	3632 B9	3807 E8	5112 F3	6607 B4	7804 F7	9623 B6	
2412 B1	2640 B6	3124 G6	3507 D8	3633 A9	3808 F8	5151 D3	6609 B9	7805 F8	9624 B6	
2413 B1	2641 B6	3125 F5	3508 C8	3634 B8	3809 E8	5152 E2	6611 A5	7811 D1	9625 C7	
2414 D1	2644 E2	3126 F6	3509 D8	3635 B9	3810 E8	5153 E4	6621 C2	8101 G2	9626 C2	
2415 D1	2645 A9	3127 G6	3510 D9	3636 B8	3811 E6	5155 E4	6623 A6	8601 D4	9628 B1	
2416 C1	2646 C7	3128 G5	3511 D8	3637 A9	3812 E7	5156 E4	6624 A5	8801 F9	9629 B1	
2417 C1	2651 A8	3129 G4	3512 D9	3638 A8	3813 F9	5601 A4	6627 C1	8802 E9	9630 A1	
2418 D1	2652 B9	3130 E2	3513 D8	3639 A8	3814 E8	5602 D5	6630 C1	8803 E8	9801 E8	
2419 A1	2653 C2	3131 G5	3514 D7	3640 A8	3815 E8	5603 C4	6633 A1	8804 F7	9814 F7	
2422 C6	2654 D2	3132 F5	3515 C7	3641 B8	3816 F8	5604 C5	6634 A3	8805 E1	9815 E8	
2423 D7	2655 C1	3133 G4	3516 C7	3642 B9	3817 F8	5606 A5	6801 E8	8806 A2	9816 F8	
2424 B5	2656 A1	3134 F8	3517 E5	3643 A9	3818 F8	5608 B3	6802 F9	8807 D1	9818 E8	
2425 C7	2657 A1	3135 D2	3518 E6	3644 C8	3819 F7	5610 C3	6803 F9	9101 D4	9820 F9	
2426 D7	2658 A3	3136 G1	3519 D9	3645 C8	3820 F7	5611 A7	6804 E8	9102 F1	9821 E9	
2501 D8	2659 A3	3138 G1	3520 C8	3646 B9	3821 F7	5612 B2	6807 F9	9103 G2	9822 D8	
2502 D5	2660 A3	3139 F8	3521 B3	3647 A9	3823 F9	5613 D2	7102 E2	9104 G2	9823 E9	
2503 B8	2661 A1	3151 E3	3522 D4	3648 D2	3824 E9	5801 E6	7103 F5	9111 F2	9825 F8	
2504 B8	2665 B8	3153 E2	3523 B9	3649 C2	3825 F7	6102 G2	7105 G4	9112 G3	9826 E9	

Video Panel (A) C.B.A. (SMC)



Go to cover page


2301	E2	3362	E4
2302	E1	3363	E4
2304	E5	3372	E1
2305	E5	3376	E1
2306	E5	3378	C2
2307	C5	3379	E4
2308	D5	3380	E4
2309	E1	3702	B4
2310	D5	3707	D1
2311	D5	3725	A3
2312	E2	3730	D2
2316	D5	3735	A3
2317	D5	3740	E2
2318	D5	3741	C1
2319	E1	3742	C1
2322	E2	3743	C2
2323	E2	3744	B2
2325	D2	3745	C2
2326	E2	3755	A1
2341	E3	3761	E3
2342	E4	3762	E3
2343	E4	3763	E3
2344	E4	3764	E3
2345	E2	3765	E3
2346	E1	3767	D3
2347	E1	3776	B5
2349	A5	3777	B5
2350	E4	3778	B5
2702	C2	3782	A4
2722	C2	3783	B3
2726	C2	6721	B2
2728	C2	6724	C2
2739	B2	6731	B3
2740	C2	6734	B2
2760	E3	6754	D2
2761	E3		
2763	E3		
2771	C3		
2777	A4		
2781	E5		
2782	E5		
3301	D5		
3302	D5		
3303	D5		
3305	E5		
3306	E5		
3307	C5		
3309	E2		
3311	E2		
3312	D5		
3313	D5		
3314	D5		
3315	E1		
3316	D1		
3324	E3		
3326	E3		
3327	E2		
3328	E2		
3329	D2		
3330	D2		
3331	E3		
3334	E3		
3335	E1		
3336	E1		
3337	E2		
3338	E3		
3339	E3		
3341	D4		
3342	E4		
3343	E4		
3347	E4		
3348	E4		
3350	E4		
3355	E3		
3360	E4		
3361	E4		



Click here for Video Panel C.B.A. (HMC)


Click here for Video Panel C.B.A. (SMC)

Video Panel (A) C.B.A. (HMC)




1301	D5	3757	A2
1703	B4	3758	D1
1711	C3	3760	B5
1712	C4	3771	B5
1713	C5	3772	D4
1714	A5	3773	A4
1715	C3	3775	C2
2324	D2	3779	A4
2348	E4	3781	B5
2721	B2	3784	D5
2723	C2	3785	D5
2724	A3	5301	D1
2725	D3	5303	E2
2731	B2	5701	D1
2732	A4	5702	C1
2733	C2	5721	B2
2751	D2	5732	B2
2752	A1	5752	C2
2753	B3	5771	B4
2762	D3	5772	D5
2772	D3	5773	E5
2773	B4	5779	C1
2775	B4	5781	B3
2776	B3	5784	C4
2778	E1	5786	A5
2779	C5	6301	E5
2780	C5	6302	E5
2783	E1	6303	E5
2785	B4	6304	E5
2786	C4	6711	B5
3310	E2	6722	B2
3325	D3	6732	B2
3332	D3	6751	D1
3333	E3	6752	D2
3344	D4	6771	D4
3345	D4	6772	A4
3346	D5	7301	E1
3349	E4	7302	E4
3351	E4	7303	E4
3352	D4	7304	E3
3353	D4	7322	D3
3354	D3	7701	C2
3356	E4	7702	A4
3357	E4	7721	A2
3358	E4	7722	A2
3359	D4	7731	A3
3701	A3	7732	A4
3703	D2	7751	A1
3704	D1	7752	A1
3705	D2	7761	E3
3706	D1	8301	D5
3713	D2	9783	D1
3716	D2	9791	C1
3718	C5		
3719	C5		
3720	D5		
3721	C2		
3722	B2		
3723	B2		
3724	A2		
3726	B3		
3727	A3		
3728	B2		
3729	D5		
3731	B2		
3732	B2		
3733	A4		
3734	A3		
3736	A3		
3737	A3		
3738	B3		
3751	D3		
3752	D2		
3753	A1		
3754	C1		
3756	A2		



Video Panel (A) Schematic Diagram & Waveforms for Diagram (A)



Block diagram



Control panel Schematic Diagram & C.B.A.



Go to cover page

All units that are returned for service or repair must pass the original manufactures safety tests. Safety testing requires both **Hipot** and **Ground Continuity** testing.

HI-POT TEST INSTRUCTION

1. Application requirements

- 1.1 All mains operated products must pass the Hi-Pot test as described in this instruction.
- 1.2 This test must be performed again after the covers have been refitted following the repair, inspection or modification of the product.

2. Test method

2.1 Connecting conditions

- 2.1.1 The test specified must be applied between the parallel-blade plug of the mainscord and all accessible metal parts of the product.
- 2.1.2 Before carrying out the test, reliable conductive connections must be ensured and thereafter be maintained throughout the test period.
- 2.1.3 The mains switch(es) must be in the "ON" position.

2.2 Test Requirements


All products should be HiPot and Ground Continuity tested as follows:

Condition	HiPot Test for products where the mains input range is Full range(or 220V AC)	HiPot Test for products where the mains input is 110V AC(USA type)	Ground Continuity Test requirement
Test voltage	2820VDC (2000VAC)	1700VDC (1200VAC)	Test current: 25A,AC Test time: 3 seconds(min.) Resistance required: <=0.09+R ohm, R is the resistance of the mains cord.
Test time (min.)	3 seconds	1 second	
Trip current (Tester)	set at 100 uA for Max. limitation; set at 0.1 uA for Min. limitation	5 mA	
Ramp time	set at 2 seconds		

- 2.2.1 The test with AC voltage is only for production purpose, **Service center shall use DC voltage.**
- 2.2.2 The minimum test duration for Quality Control Inspector must be 1 minute. No breakdown during the test.
- 2.2.3 The test voltage must be maintained within the specified voltage + 5%.
- 2.2.4 The grounding blade or pin of mains plug must be conducted with accessible metal parts.

3. Equipments and Connection

- 3.1. Equipments
For example :
 - ChenHwa 9032 PROGRAMMABLE AUTO SAFETY TESTER
 - ChenHwa 510B Digital Grounding Continuity Tester
 - ChenHwa 901 (AC Hi-pot test), 902 (AC, DC Hi-pot test) Withstanding Tester
- 3.2. Connection
 - * Turn on the power switch of monitor before Hipot and Ground Continuity testing.



(ChenHwa 9032 tester)

Video cable

Connect the "video cable" or "grounding screw" to the CLIP on your tester.

Grounding screw

Connect the power cord to the monitor.

Power outlet

(Rear view of monitor)

4. Recording

Hipot and Ground Continuity testing records have to be kept for a period of 10 years.

0. General

When carry-out the electrical settings in many cases a video signal must be applied to the monitor. A computer with :

- ATI GPT-1600 (4822 397 10065), Mach 64 (up to 107kHz)

are used as the video signal source. The signal patterns are selected from the "service test software" package, see user guide 4822 727 21046 (GPT-1600).

0.1 This monitor has 9 factory-preset modes as below.

1.	640 x 350	31.5 Khz	70 HZ(VESA)
2.	640 x 400	31.5 Khz	70 HZ(VESA)
3.	640 x 480	43.2 Khz	85 HZ(VESA)
4.	800 x 600	46.9 Khz	75 HZ(VESA)
5.	800 x 600	53.7 Khz	85 HZ(VESA)
6.	1024 x 768	60.0 Khz	75 HZ(VESA)
7.	1024 x 768	68.7 Khz	85 HZ(VESA)
8.	1280 x 1024	80.0 Khz	75 Hz (VESA)
9.	1280 x 1024	91.1 Khz	85 Hz (VESA)

0.2 With normal VGA card:

If not using the ATI card during repair or alignment, The service engineer also can use this service test software adapting with normal standard VGA adaptor and using standard VGA mode 1024 x 768, 68.7 kHz/85 Hz (only) as signal source.

0.3 AC/DC Measurement:

The measurements for AC waveform and DC figure is based on 1024 x 768 68.7 kHz/85 Hz resolution mode with test pattern "gray scale". Power input: 110V AC

1. B+ supply voltage (3165) 84Vdc

- Apply a video signal in the 1024 x 768 with 68.7 kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Pre-set trimming potentiometer 3165(+) and 3698(EHT) in mid-position.
- Set Vg2 (screen) to fully Counter-clockwise (zero beamcurrent).
- Connect a dc voltmeter between the joint of capacitor 2152 and ground (common ground).
- Set the B+ trimming potentiometer 3165 so that the reading on the dc voltmeter is 185 V +/- 0.2 Vdc.

2. High-voltage EHT (3698)

- Apply a video signal in the 1024 x 768 with 68.7kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Connect a "high-voltage voltmeter" between the high-voltage connection of the picture tube and earth.
- Turn on the power.
- Set the EHT trimming potentiometer 3698 so that the "high-voltage voltmeter" reads 25.0 kV +/- 0.2 kV .
- Turn off the power.
- Remove the "high-voltage voltmeter" from the picture tube.
- Turn on the power again.

3. Monitor the following auxiliary voltages.

SOURCE ACROSS C2152 and GND.	+185.0V +/- 1.5 VDC
SOURCE ACROSS C2154	+ 82.0V +/- 1.5 VDC.
SOURCE ACROSS C2156	- 6.4 V +/- 0.3 VDC.
SOURCE ACROSS C2160	+13.5V +/- 0.5 VDC.
SOURCE ACROSS C2157	- 14.0V +/- 0.5 VDC.

4. General conditions for alignment

- 4.1 During all alignments, supply a distortion free AC mains voltage to set via an isolating transformer with low internal impedance.
- 4.2 Align in pre-warmed condition, at least 30 minutes warm-up with nominal picture brightness.
- 4.3 Purity, geometry and subsequent alignments should be carried out in magnetic cage with correct magnetic field.

Northern hemisphere : H=0, V=430 +/- 50 mG, Z=0
Southern hemisphere : H=0, V=-520 +/-50 mG, Z=0


- 4.4 All voltages are to be measured or applied with respect to ground.

Note: Do not use heatsink as ground.

- 4.5 Adjust brightness controls to center position except for contrast control which should be set to MAX.

5. To access factory mode:

- Turn off monitor (don't turn off PC)
- Press " " and " " simultaneously on the front control panel ,then press " ",wait till the OSD menu with characters " factory mode (below OSD menu)" come on the screen of monitor.



- If OSD menu disappears on the screen of monitor, press " " again (anytime), then the OSD menu comes on the screen again.
- using " " : to select OSD menu.
- using " " : to increase or decrease the setting. (Please also refer to page 8 to page 15 for OSD adjustment)
- Using " " to confirm the selection.

5.1. To leave factory mode

After alignment of factory mode, turn off monitor (if you do not turn off monitor, the OSD menu is always at the factory mode), then turn on monitor again (at this moment, the OSD menu goes back to user mode).

Go to cover page

6. Picture geometry setting

- Apply a video signal with cross-hatch pattern.
- Apply a video signal in the 1024 x 768 with 68.7 kHz/85 Hz mode.
- Set contrast control at Max. position, and brightness control in the mid-point.

6.4 Alignment of horizontal geometry and vertical geometry

- 6.4.1 Adjust the H-width to 306 mm
- 6.4.2 Adjust the H-phase to center position.
- 6.4.3 Adjust V-size to 230mm.
- 6.4.4 Adjust V-Position to center.

Adjust/Trapezium/pincushion

- 6.4.5 Adjust picture tilt via I²C BUS for correct top/bottom lines.
- 6.4.6 Adjust the top and bottom corner by I²C to straight vertical lines of the left and right edge.
- 6.4.7 Adjust the parallelogram by I²C BUS to get optimum vertical line.
- 6.4.8 Adjust the unbalance pin by I²C BUS to get optimum vertical line.
- 6.4.9 Adjust the unbalance Vertical linearity balance by I²C BUS to get optimum vertical linearity balance.
- 6.4.10 Adjust the unbalance Vertical linearity by I²C to get optimum vertical linearity.
- 6.5 Adjust size/centering/trapezium/pincushion/parallelogram of all other preset modes via I²C bus.

7. Alignment of Vg2 cut-off point, white tracking

Equipment : 1. Video Test Generator-801GC (Quantum Data)
2. Color-analyzer (Minolta CA-100)

VG2 [(screen), at the bottom of the L.O.T.].

- * Apply a video signal in the 1024 x 768 with 68.7 kHz/85 Hz mode, select the "full white pattern" (sizes 306 x 230 mm).

- * Use color-analyzer (Minolta CA-100) to adjust cutoff and white uniformity.

Brightness = 50%, Sub-Contrast = 190%, ABL = 128% (I² C)
OSD R/G/B cut-off and R/G/B gain can be accessed, with initial data:

9300 °K

R cutoff = 128%, R gain = 180% (I² C)

G cutoff = 128%, G gain = 180% (I² C)

B cutoff = 128%, B gain = 180% (I² C)

6500 °K

R cutoff = 128%, R gain = 160% (I² C)

G cutoff = 128%, G gain = 160% (I² C)

B cutoff = 128%, B gain = 160% (I² C)

5500 °K

R cutoff = 128%, R gain = 150% (I² C)

G cutoff = 128%, G gain = 150% (I² C)

B cutoff = 128%, B gain = 150% (I² C)

Step 1: To press power button switch and left & right simultaneously to enter the character "FACTORY MODE" as shown in Fig.2.1, press " " to access the OSD menu for R/G/B gain & cutoff as shown in Fig. 2.2.

Step 2: Press " " for function selection as shown in Fig. 2.2.



Fig. 2.1




Fig. 2.2

BIAS R G B : R(red) G(green) B(blue) cutoff

GAIN R G B : R(red) G(green) B(blue) gain

V FOCUS : Vertical Focus

VLIN BAL : Vertical Linearity Balance

USER : Horizontal size range

RASTER H: Horizontal DC (raster) Shift

RASTER V: Vertical DC (raster) Shift

HLIN : Horizontal Linearity

V LIN : Vertical Linearity

SUB : Zoom range

SUB : Sub Contrast

V OFFSET : Vertical offset

V GAIN : Vertical Gain

ABL : Auto Beam Limit

T CORNER: Corner Correction of TOP

B CORNER: Corner Correction of BOTTOM

CONVERGENCE(V H): CONVERGENCE Correction of Vertical, Horizontal.

VE(HILI SHARP): Video Enhance of HighLight, SHARPness

(VE Adjustment Range from 1(10%) to 4(40%))

(VE Is also LightFrame)

7.2 Connect the video input, set brightness control at center, and contrast control at maximum

7.3 set

	9300°K	6500°K	5500°K
R cut-off	128	128	128
G cut-off	128 (Fix)	128 (Fix)	128 (Fix)
B cut-off	128	128	128
R gain	180 (I ² C)	160 (I ² C)	150 (I ² C)
G gain	180 (Fix) (I ² C)	160 (Fix) (I ² C)	150 (Fix) (I ² C)
B gain	180 (I ² C)	160 (I ² C)	150 (I ² C)

7.4 Adjust 9300K color:

With the help of a factory calibrated color analyzer CA 100

set low R,G,B scale 100=0.07FL,x=0.283,y=0.297

Adjust Vg1 until brightest gun at 100 on low brightness scale.

7.5 Adjust R,G,B cut-off for all gun reading to get 100 on low brightness scale.

7.5 Adjust R,G,B cut-off for all gun reading to get 100 on low brightness scale.

7.6 Set Ca100 high R,G,B scale 100 = 40+/- 1FL,X=0.283,y=0.297
Adjust G gain at 100 scale on high brightness scale.

7.7 Adjust R,B gain so that blue and green having as red on the high brightness scale

7.8 Set contrast at minimum and repeat 7.5,7.6,7.7,until RGB three guns get same readings on low and high brightness scale.

7.9 Adjust 6500K color:

With the help of a factory calibrated color analyzer CA 100

set low R,G,B scale 100=0.07FL,x=0.313,y=0.329

Adjust Vg1 until brightest gun at 100 on low brightness scale.

7.10 Adjust R,G,B cut-off for all gun reading to get 100 on low brightness scale.

7.11 Set CA100 high R,G,B scale 100 = 40+/- 1FL,X=0.313,y=0.329
Adjust G gain at 100 scale on high brightness scale.

7.12 Adjust R,B gain so that blue and green have the same reading as red on the high brightness scale

7.13 Set contrast at minimum and repeat 7.10,7.11,7.12,until RGB three guns get same readings on low and high brightness scale.

7.14 Adjust SUB-CON to get Y=40+/-6FL.

7.15 Apply full white pattern, adjust ABL to reach 31 +/- 0.5 FL(9300K)

7.16 Check full white at contrast and brightness at minimum, the foreground shall be extinguished.

8. Focus adjustment

Apply a signal of " @ " character. at 68.7 kHz/85 Hz mode set the brightness to mid-position , contrast to max - position and adjust the focus for optimal sharpness in the area within 2/3 from the screen center.

9. Loading DDC code

The DDC HEX data(refer sheet 190) should be written into the EEPROM (7804) ,0~127 bytes by EEPROM writer or equivalent method.

10. To access service mode

The service mode is for service purpose which convenient to perform repair service and pre-warm up monitor before test or re-adjustment colour temperature without any video signal generator requirement.

- 10.1 Remove video signals
- 10.2 Press " ◀ " and " ▶ " simultaneously on the front control panel ,then press " ⏻ ",release all buttons till the full white pattern come on the screen of monitor.
- 10.3 In the beginning of service mode (full white pattern), the monitor will working at 48kHz of horizontal frequency, after 55 seconds, it will switch to 81kHz automatically, then change mode between two modes constantly every 55 seconds.
- 10.4 You may quit service mode by either turn off and on or feed video signals to the monitor.

11. Purity adjustment

- Make sure the monitor is not exposed to any external magnetic field.
- Produce a full red pattern on the screen, adjust the purity magnet rings on the PCM assy (on CRT) to obtain a complete field of the color red. This is done by moving the two tabs (2-pole) in such a manner that they advance in an opposite direction but at the same time to obtain the same angle between the two tabs, which should be approximately 180 degree.
- Check by full green pattern and full blue pattern again to observe their respective color purity.


12. Static convergence

Introduction


Slight deviation in the static convergence can be corrected by using two permanent pairs of magnets which are fitted around the neck of the CRT. These are the 4-pole magnet and the 6-pole magnet. The 4-pole magnet move the outermost electron beams (R and B) parallel in the opposite direction from the other. The 6-pole magnet moves the outermost electron beam (R, B and G) parallel in the opposite direction from the other. The magnetic field of the above magnets do not affect the center of the CRT neck.

Setting


- Before the static convergence setting can be made, the monitor must be switched on for 30 minutes.
- The focus setting must be made correctly.
- Signal: 640 * 480, 31.5 kHz/60 Hz mode.
- Set the tabs of the 4-pole magnet in the neutral position. This is when the tabs are opposite one another. In this position the magnets do not affect the deflection of the R and B electron beams.
- Set the tabs of the 6-pole magnet in the neutral position. This is when the tabs are opposite one another. In this position the magnets do not affect the deflection of the R, B, and G electron beams.
- First set the 4-pole magnet optimally.
- Then set the 6-pole magnet optimally.
- If the convergence is not now optimal, then adjust to the optimal setting with the 4-pole magnet and then with the 6- Pole magnet again.
- Set the tabs of the 6-pole magnet in the neutral position. This is when the tabs are opposite one another. In this position the magnets do not affect the deflection of the R, B, and G electron beams.
- First set the 4-pole magnet optimally.
- Then set the 6-pole magnet optimally.
- If the convergence is not now optimal, then adjust to the optimal setting with the 4-pole magnet and then with the 6- pole magnet again.



4-pole Beam motion produced by the 4-pole convergence magnet



6-pole Beam motion produced by the 6-pole convergence magnet



◀◀ Go to cover page

EDID log file

Vendor/Product Identification

ID Manufacturer Name : PHL
ID Product Code : E002 (HEX.)
ID Serial Number : ***** (HEX.)
Week of Manufacture : 26
Year of Manufacture : 2000

EDID Version, Revision

Version : 1
Revision : 1

Basic Display Parameters/Features

Video Input Definition : Analog Video Input
0.700V/0.000V (0.70Vpp)
without Blank-to-Black Setup
Separate Sync
Composite Sync
without Sync on Green
no Serration required

Maximum H Image Size : 325
Maximum V Image Size : 244

Display Transfer Characteristic (gamma) : 2.65

Feature Support (DPMS) : Standby
Suspend
Active Off

Display Type : RGB color display

Color Characteristics

Red X coordinate : 0.625
Red Y coordinate : 0.34
Green X coordinate : 0.29
Green Y coordinate : 0.605
Blue X coordinate : 0.15
Blue Y coordinate : 0.07
White X coordinate : 0.283
White Y coordinate : 0.297

Established Timings

Established Timings I : 720 x 400 @ 70Hz (IBM,VGA)
640 x 480 @ 60Hz (IBM,VGA)
640 x 480 @ 75Hz (VESA)

Established Timings II : 800 x 600 @ 75Hz (VESA)
1024 x 768 @ 75Hz (VESA)
1280 x 1024 @ 75Hz (VESA)

Manufacturer's timings :

Standard Timing Identification #1

Horizontal active pixels : 640
Aspect Ratio : 4:3
Refresh Rate : 85

Standard Timing Identification #2

Horizontal active pixels : 800
Aspect Ratio : 4:3
Refresh Rate : 85

Standard Timing Identification #3

Horizontal active pixels : 1024
Aspect Ratio : 4:3
Refresh Rate : 85

Standard Timing Identification #4

Horizontal active pixels : 1280
Aspect Ratio : 5:4
Refresh Rate : 85

Standard Timing Identification #5

Horizontal active pixels : 1280
Aspect Ratio : 4:3
Refresh Rate : 85

Detailed Timing #1

Pixel Clock (MHz) : 157.5
H Active (pixels) : 1280
H Blanking (pixels) : 448
V Active (lines) : 1024
V Blanking (lines) : 48
H Sync Offset (F Porch) (pixels) : 64
H Sync Pulse Width (pixels) : 160
V Sync Offset (F Porch) (lines) : 1
V Sync Pulse Width (lines) : 3
H Image Size (mm) : 306
V Image Size (mm) : 230
H Border (pixels) : 0
V Border (lines) : 0
Flags : Non-interlaced
: Normal Display, No stereo
: Digital Separate sync.
: Positive Vertical Sync.
: Positive Horizontal Sync.

Monitor Descriptor #2

Serial Number : TY 002267

Monitor Descriptor #3

Monitor Name : Philips 107P2

Monitor Descriptor #4

Monitor Range Limits
Min. Vt rate Hz : 50
Max. Vt rate Hz : 160
Min. Horiz. rate kHz : 30
Max. Horiz. rate kHz : 92
Max. Supported Pixel : Not specified

Extension Flag

Check sum : 96 (HEX.)

EDID data (128 bytes)

0: 00 1: ff 2: ff 3: ff 4: ff 5: ff 6: ff 7: 00
8: 41 9: 0c 10: 6a 11: 79 12: 01 13: 00 14: 00 15: 00
16: 05 17: 0a 18: 01 19: 01 20: 7e 21: 20 22: 18 23: a5
24: e8 25: 04 26: 88 27: a0 28: 57 29: 4a 30: 9b 31: 26
32: 12 33: 48 34: 4c 35: a4 36: 43 37: 00 38: 31 39: 59
40: 45 41: 59 42: 61 43: 59 44: 81 45: 99 46: a9 47: 4f
48: 01 49: 01 50: 01 51: 01 52: 01 53: 01 54: 68 55: 5b
56: 80 57: a8 58: 72 59: a0 60: 3c 61: 50 62: 80 63: d0
64: 13 65: 00 66: 32 67: e6 68: 10 69: 00 70: 00 71: 1e
72: 00 73: 00 74: 00 75: ff 76: 00 77: 20 78: 54 79: 59
80: 20 81: 20 82: 30 83: 30 84: 32 85: 32 86: 36 87: 37
88: 0a 89: 20 90: 00 91: 00 92: 00 93: fc 94: 00 95: 50
96: 48 97: 49 98: 4c 99: 49 100: 50 101: 53 102: 20 103: 31
104: 30 105: 37 106: 50 107: 0a 108: 00 109: 00 110: 00 111: fd
112: 00 113: 32 114: a0 115: 1e 116: 60 117: ff 118: 00 119: 0a
120: 20 121: 20 122: 20 123: 20 124: 20 125: 20 126: 00 127: 96

*note: Address 78 & 79 for factory code:

For example : fill in "54" & "59" at address 78 & 79, it stands for "TY".
fill in "48" & "43" at address 78 & 79, it stands for "HC".

Factory code for each site is as below.

Brazil	H C (48h, 43h)	Shenzhen	C X (43h, 58h)
Chungli	T Y (54h, 59h)	Suzhou	B Z (42h, 5Ah)
Delta	G K (47h, 4Bh)	Szombathely	H D (48h, 44h)
Juarez	Y A (59h, 41h)	Raleigh	IO (49h, 4Fh)

serial no. address : 82, 83, 84, 85, 86, 87, 88, 89

For example, Monitor Descriptor #2

Serial Number:

□ TY (or HC, YA, BZ ... etc) □□ SSSSSS ----- for PHILIPS Brand

blank blank

S: stands for "serial number"

◀ Back

Forward ▶

Go to cover page

1. General

DDC Data Re-programming

In case the main EEPROM with Software DDC which store all factory settings were replaced because a defect, repaired monitor' the serial numbers have to be re-programmed.

It is advised to re-soldered the main EEPROM with Software DDC from the old board onto the new board if circuit board have been replaced, in this case the DDC data does not need to be re-programmed.

Additional information

Additional information about DDC (Display Data Channel) may be obtained from Video Electronics Standards Association (VESA). Extended Display Identification Data(EDID) information may be also obtained from VESA.

DDC EDID structure
For the monitor : Standard Version 3.0
Structure Version 1.3

2. System and equipment requirements

- 1. An i486 (or above) personal computer or compatible.
 - 2. Microsoft operation system Windows 95/98.
 - 3. EDID301.EXE program (3138 106 10103) shown as Fig. 1
 - 4. Software DDC Alignment kits (4822 310 11184) shown as Fig. 2.
- The kit contents: a. Alignment box x1
b. Printer cable x1
c. D-Sub cable x1

Note: The EDID301.EXE (Release Version 1.55) is a windows-based program, which cannot be run in MS-DOS.




Figure 1 Diskette with EDID301.EXE





Fig. 2 Alignment Kits

3. Pin assignment

A. 15-pin D-Sub Connector

The 15-pin D-sub connector (male) of the signal cable on the 3rd row for DDC feature :



Pin No.	Assignment	Pin No.	Assignment
1	Red video input	9	No pin
2	Green video input	10	Logic ground
3	Blue video input	11	Identification output - Connected to pin 10
4	Identification output - Connected to pin 10	12	Serial data line(SDA)
5	Ground	13	H.Sync
6	Red video ground	14	V.Sync(VCLK for DDC)
7	Green video ground	15	Data clock line(SCL)
8	Blue video ground		

4. Configuration and procedure

Following descriptions are the connection and procedure for Software DDC, the main EEPROM can be re-programmed along with Software DDC by enabling "factory memory data write" function on the DDC program (EDID301.EXE).

To access factory mode:

Turn off monitor (don't turn off PC)
- Press " " and " " simultaneously on the front control panel ,then press " ",wait till the OSD menu with characters " factory mode (below OSD menu)" come on the screen of monitor.

Initialize alignment box

In order to avoid that monitor entering power saving mode due to sync will cut off by alignment box, it is necessary to initialize alignment box before running programming software (EDID301.EXE). Following steps show you the procedures and connection.

- Step 1: Supply 8~12V DC power source to the Alignment box by plugging a DC power cord or using batteries.
- Step 2: Connecting printer cable and video cable of monitor as Fig. A
- Step 3: Run the EDID301.EXE program until the main menu appears.
This is for initialize alignment box.




Fig. A

Re-programming Software DDC

- Step 1: After initialize alignment box, connecting all cables and box as Fig. 3
- Step 2: Follow the steps on DDC re-programming instructions to starting re-programming.





Fig. 3

5. DDC re-programming instructions

Start on DDC program

- Start Microsoft Windows.
- 1. Insert the disk containing EDID301.EXE program into floppy disk drive.
- 2. Click **Start** , choose Run at start menu of Windows 95/98.



- 4. At the submenu, type the letter of your computer's floppy disk drive followed by :EDID301 (for example, A:\EDID301, as shown in Fig. 5).





Fig. 5

Go to cover page

5. Click  button. The main menu appears (as shown on Fig. 6).








Fig. 6

Note: If the connection is improper, you will see the following error message before entering the main menu. Meanwhile, the  (read EDID) function will be disable. At this time, please make sure all cables are connected correctly and fixedly, and the procedure has been performed properly.



Loading DDC data from monitor

1. Click  icon on the tools bar to bring up the Configuration Setup windows as Fig.7
2. Select the DDC2B as the communication channel.
3. Enable Factory memory data write function and fill in page address "F0" to the block.
- 4.. Click  button to confirm your selection.

Note: The Factory memory data write function will allow EDID301 to rewrite the serial numbers of Software DDC data in main EEPROM.






Fig. 7

4. Click  icon to read DDC EDID data from monitor. The EDID codes will display on screen as following. (The EDID codes are dependent on the model.)



Note: During the loading, EDID301 will verify the EDID data which just loaded from monitor before proceed any further function, once the data structure of EDID can not be recognized, the following error message will appear on the screen (Fig. 8). Please confirm following steps to avoid this message.

1. The data structure of EDID was incorrect.
2. Software DDC Data that you are trying to load data is empty.
3. Wrong communication channel has set at configuration setup windows.
4. Cables loosed or poor contact of connection.
5. ☐ Software DDC only is disable.











Fig. 8

Modify DDC data (Serial No.)

1. Click  icon on the tool bar.
2. Click  till the Step 7 of 9 window appears.
3. Type the new Serial No. (for example, TY 123456).
4. Click  till the last step window appears, then click  to exit the Step window.






Write DDC data to monitor

1. Click  icon from the tools bar to starting rewrite DDC data.
2. Click  for confirmation.



Save DDC data as a file


Sometimes, you maybe need to save DDC data as a text file for using on other DDC chip. To save DDC data, follow the steps below:

1. Click  icon on the tools bar and type a file name you like. The file format is ddc type which can be open by Microsoft WordPad.
2. Click  button.



Load DDC data from file


1. Click  from the tools bar.
2. Select the file you want to open.
3. Click  Button.



4. Now you can re-programming DDC data which you just loaded from a file, please be confirmed that model and serial number are correct and match with the monitor you are trying to re-write.

Exit DDC program


1. Click file command on the command bar then select Exit.



Definition of Serial Number

T Y 0 0 9 9 2 8 0 0 0 0 1

- Serial Number (U.S.A: 8 digit)
(Others regions: 6 digit)
- Week
- Year
- TY Code
TY----Chungli
CX----Dong Guan
HD----Hungary
BZ----Suzhou



Go to cover page

0. General

To be able to perform measurements and repairs on the "circuit boards", these unit should placed in the service position first.

1.Remove the rear cover

There are 2 screws in the lid [1 screw are at the right side of the monitor, The other 1 screw are at the left side of the monitor],to fix the front cabinet and back cover of the monitor.

- Step 1: To open the lid at the right-upper side and 1screw in right-downer side of the monitor.(FIG.3)
- Step 2: To open the lid at the left-upper side and 1screw in left-downer side of the monitor.(FIG.4)
- Step 3: To remove the backcover, you can see FIG.5
- Step 4: To remove the 5 screws on the bottoml shield, and remove the bottoml shield, you can see FIG.1.

2. Video panel(1157)

- a.Cutoff all wire cable ties
- b.Remove GRD wire between video shield and CRT rack.
- c.Remove 1 screw between mains board rack and video shield
- d. cutoff 1 cable tie on LOT wire
- e.Remove GRD wire (1711)from video PCB to CRT rack.

3. Main panel(1155)

- Disconnect the degaussing coil (1113)from Main panel.
- Remove the video panel from CRT.
- Remove the "screw" of I/F cable from Main panel.
- Disconnect the CRT ground wire from main panel.
- Disconnect the Hi-Pot cap from CRT.
- Disconnect yoke wire from "1401".
- Disconnect the control panel(1802)
- Slide the main panel out of bottom tray.
- Connect yoke wire to "1401".
- Connect the control panel(1802)
- Place Main panel in service position as shown in Fig.1.
- Mount Video panel again on CRT.
- To connect Hi-Pot cap again.



Fig.2




Fig.3




Fig.4




Fig.5



Fig.6

4. service position



1157 VIDEO Panel 1155 MAIN Panel

Fig.1





Fig.7

Warnings

1. Safety regulations require that the unit should be returned in its original condition and that components identical to the original components are used. The safety components are indicated by the symbol .
2. In order to prevent damage to ICs and transistors, all high-voltage flash-overs must be avoided. In order to prevent damage to the picture tube, the method shown in Fig. 1 should be used to discharge the picture tube. Use a high-voltage probe and a multimeter (position DC-V). Discharge until the meter reading is **0 V** (after approximately 30 seconds).
3. **ESD**
All ICs and many other semiconductors are sensitive to electrostatic discharges (ESD). Careless handling during repair can drastically shorten their life. Make sure that during repair you are connected by a pulse band with resistance to the same potential as the ground of the unit. Keep components and tools also at this same potential.
4. When repairing a unit, always connect it to the AC Power voltage via an isolating transformer.
5. Be careful when taking measurements in the high-voltage section and on the picture tube panel.
6. It is recommended that safety goggles be worn when replacing the picture tube.
7. When making adjustments, use plastic rather than metal tools. This will prevent any short-circuit or the danger of a circuit becoming unstable.
8. Never replace modules or other components while the unit is switched on.
9. Together with the deflection unit, the picture tube is used as an integrated unit. Adjustment of this unit during repair is not recommended.
10. After repair, the wiring should be fastened in place with the cable clamps.
11. All units that are returned for service or repair must pass the original manufacturer's safety tests.

Notes

1. The direct voltages and waveforms are average voltages. They have been measured using the Service test software and under the following conditions :
 - Mode : 640 * 480 (31.5kHz / 60Hz)
 - Signal pattern : grey scale
 - Adjust brightness and contrast control for the mechanical mid-position (click position)
2. The picture tube panel has printed spark gaps. Each spark gap is connected between an electrode of the picture tube and the Aquadag coating.
3. The semiconductors indicated in the circuit diagram(s) and in the parts lists are completely interchangeable per position with the semiconductors in the unit, irrespective of the type indication on these semiconductors.




Fig.1



OSD Adjustments

◀◀ Go to cover page





The OSD Controls

BRIGHTNESS

To adjust your screen's brightness, follow the steps below. Brightness is the overall intensity of the light coming from the screen. A 50% brightness is recommended.

- 1) Press the  or  button on the monitor. The BRIGHTNESS window appears.






- 2) Press the  or  button to adjust the brightness.
- 3) When the brightness is adjusted to the level desired, stop pressing the  or  button and after three seconds the BRIGHTNESS window will disappear with the new adjustment saved.





Smart Help After the BRIGHTNESS window has disappeared, to continue to the CONTRAST window, follow the steps under CONTRAST.

CONTRAST

To adjust your screen's contrast, follow the steps below. Contrast is the difference between the light and dark areas on the screen. A 100% contrast is recommended.



- 1) Press the  or  button on the monitor. The CONTRAST window appears.





- 2) Press the  or  button to adjust the contrast.
- 3) When the contrast is adjusted to the level desired, stop pressing the  or  button and after three seconds the CONTRAST window will disappear with the new adjustment saved.


Smart Help After the CONTRAST window has disappeared, to continue to the MAIN CONTROLS, follow the steps under LANGUAGE


The ON SCREEN DISPLAY shows its settings in one of five languages. The default is English, but you can select French, Spanish, German, or Italian.

- 1) Press the  button on the monitor. The MAIN CONTROLS window appears. LANGUAGE should be highlighted.
- 2) Press the  button again. The LANGUAGE window appears.





- 3) Press the  or  button until the desired language is highlighted.



- 4) Press the  button to confirm your selection and return to MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted...



Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to INPUT SIGNAL SELECTION, press the  button until INPUT SIGNAL SELECTION is highlighted. Next, follow steps 3 - 5 under INPUT SIGNAL SELECTION.


. . . to exit completely, press  the button


INPUT SIGNAL SELECTION (Not available in all models)



INPUT SIGNAL SELECTION determines what you see on the screen. The default setting is INPUT A, but if the video input signal is different than the output signal, you may want to change it to INPUT B.?


- 1) Press the  button on the monitor. The MAIN CONTROLS window appears.
- 2) Press the  button until INPUT SIGNAL SELECTION is highlighted.



3) Press the  button. The INPUT SIGNAL SELECTION window appears.




4) Press the  or  button to highlight INPUT B or INPUT A.

5) Press the  button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.


Smart Help After returning to MAIN CONTROLS . . .


. . . to continue to ZOOM, press the  button until ZOOM is highlighted. Next, follow steps 3 - 5 under ZOOM.


. . . to exit completely, press the  button


ZOOM


ZOOM increases or decreases the size of the images on your screen. To adjust the ZOOM follow the steps below.



1) Press the  button on the monitor. The MAIN CONTROLS window appears.


2) Press the  button until ZOOM is highlighted.




3) Press the  button. The ZOOM window appears.




4) Press the  or  button to adjust ZOOM.

5) Press the  button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.


Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to ADJUST HORIZONTAL, press the  button until ADJUST HORIZONTAL is highlighted. Next, follow steps 3 - 7 under ADJUST HORIZONTAL.

. . . to exit completely, press the  button


ADJUST HORIZONTAL


ADJUST POSITION under ADJUST HORIZONTAL shifts the image on your screen either to the left or right. Use this feature if your image does not appear centered. ADJUST SIZE under ADJUST HORIZONTAL expands or controls the image on your screen, pushing it out toward the left and right sides or pulling it in toward the center.



1) Press the  button on the monitor. The MAIN CONTROLS window appears.



2) Press the  button until ADJUST HORIZONTAL is highlighted.






3) Press the  button. The ADJUST HORIZONTAL window appears. ADJUST POSITION should be highlighted.




4) Press the  or  button to move the image to the left or right.


5) When the position is adjusted, press the  button to return to MAIN CONTROLS window, or press the  button to highlight ADJUST SIZE.




6) To adjust the horizontal size, press the  or  button.

7) When the size is adjusted, press the  button to return to MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.


Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to ADJUST VERTICAL, press the  button until ADJUST VERTICAL is highlighted. Next, start with step 3 under ADJUST VERTICAL and follow the directions.

. . . to exit completely, press the  button

ADJUST VERTICAL

ADJUST POSITION under ADJUST VERTICAL shifts the image on your screen either up or down. Use this feature if your image does not appear centered. ADJUST SIZE under ADJUST VERTICAL expands or controls the image on your screen, pushing it out toward the top or bottom or pulling it in toward the center.

1) Press the  button on the monitor. The MAIN CONTROLS window appears.


OSD Adjustments

◀◀ Go to cover page

2) Press the button until ADJUST VERTICAL is highlighted.




3) Press the button. The ADJUST VERTICAL window appears. ADJUST POSITION should be highlighted.



4) Press the or button to move the image up or down.

5) When the position is adjusted, press the button to return to MAIN CONTROLS window, or press the to highlight ADJUST SIZE.



6) To adjust the vertical size, press the or button.

7) When the size is adjusted, press the button to return to MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to ADJUST SHAPE, press the button until ADJUST SHAPE is highlighted. Next, start with step 3 under ADJUST SHAPE and follow the directions.

. . . to exit completely, press the button

ADJUST SHAPE

ADJUST SIDE CURVE


ADJUST SIDE CURVE under ADJUST SHAPE allows you to adjust two of the five preset options. These two options are PINCUSHION and BALANCED pincushion. Note: use these features only when the picture is not square.

1) Press the button on the monitor. The MAIN CONTROLS window appears.


2) Press the button until ADJUST SHAPE is highlighted.



3) Press the button. The ADJUST SHAPE window appears. ADJUST SIDE CURVE should be highlighted.




4) Press the button. The SIDE CURVE window appears. PINCUSHION should be highlighted.



5) To adjust the pincushion, press the or button.

6) When the pincushion is adjusted, press the button to highlight BALANCED or press the button to return to the ADJUST SHAPE window.



7) To adjust the balanced pincushion, press the or button.

8) When the balanced pincushion is adjusted, press the button to return to the ADJUST SHAPE window. BACK TO MAIN WINDOWS will be highlighted.


9) Press the button to return to the MAIN CONTROLS window, or press the button until ADJUST SIDE ANGLES is highlighted.


◀◀ Go to cover page

Smart Help After returning to MAIN CONTROLS . . .

...to continue to ADJUST SIDE ANGLES, start with step 5 under ADJUST SIDE ANGLES and follow the directions.


...to exit completely, press the  button twice.

...to adjust only the BALANCED pincushion, follow steps 1 - 4 above, then press the  button, and follow steps 7 - 9.

...to adjust only the PARALLELOGRAM, follow steps 1 - 4 above, then press the  button, and follow steps 7 - 9


ADJUST SIDE ANGLES


ADJUST SIDE ANGLES under ADJUST SHAPE allows you to adjust two of the five preset options. These two options are TRAPEZOID and PARALLELOGRAM. Note: use these features only when the picture is not square.

1) Press the  button on the monitor. The MAIN CONTROLS window appears.


2) Press the  button until ADJUST SHAPE is highlighted.






3) Press the  button. The ADJUST SHAPE window appears. ADJUST SIDE CURVE should be highlighted.






4) Press the  button to highlight ADJUST SIDE ANGLES.

5) Press the  button. The SIDE ANGLES window appears. TRAPEZOID should be highlighted.






6) To adjust the trapezoid, press the  or  button. SHAPE window.

7) When the trapezoid is adjusted, press the  button to highlight PARALLELOGRAM or press the  button to return to the ADJUST



8) To adjust the parallelogram, press the  or  button.


9) When the parallelogram is adjusted, press the  button to return to the ADJUST SHAPE window. BACK TO MAIN WINDOWS will be highlighted.

10) Press the  button to return to the MAIN CONTROLS window, or press the  button until ROTATE IMAGE is highlighted.

Smart Help After returning to MAIN CONTROLS . . .


...to continue to ROTATE IMAGE, start with step 5 under ROTATE IMAGE and follow the directions.

...to exit completely, press the  button twice.


...to adjust only the PARALLELOGRAM, follow steps 1 - 4 above, then press the  button, and follow steps 7 - 9


ROTATE IMAGE (Not available in all models)

ROTATE IMAGE under ADJUST SHAPE allows you to adjust one of the five preset options. These two options are PINCUSHION and BALANCED pincushion. Note: use this feature only when the picture is not square.


1) Press the  button on the monitor. The MAIN CONTROLS window appears.

2) Press the  button until ADJUST SHAPE is highlighted.




3) Press the  button. The ADJUST SHAPE window appears. ADJUST SIDE CURVE should be highlighted.

4) Press the  arrow until ROTATE IMAGE is highlighted.



Go to cover page

5) Press the button. The ROTATE IMAGE window appears. ROTATE should be highlighted.



- 6) To adjust the rotation, press the or button.
- 7) When the rotation is adjusted, press the button to return to the ADJUST SHAPE window. BACK TO MAIN CONTROLS should be highlighted.
- 8) Press the button to return to MAIN CONTROLS.

Smart Help After returning to MAIN CONTROLS . . .
... to continue to ADJUST COLOR, press the button until ADJUST COLOR is highlighted. Next, start with step 3 under ADJUST COLOR and follow the directions.
...to exit completely, press the button twice.

ADJUST COLOR

Your monitor has two preset options you can choose from. The first option is for GENERAL USE, which is fine for most applications. The second option is for GAMES, which is for playing computer games. When you select one of these options, the monitor automatically adjusts itself to that option. There is also a third option, USER PRESET, which allows you to adjust the colors on your screen to a setting you desire.

1) Press the button on the monitor. The MAIN CONTROLS window appears.


2) Press the button until ADJUST COLOR is highlighted.



3) Press the button. The ADJUST COLOR window appears.



- 4) Press the or button to highlight 9300K for GENERAL USE, 6500K for GAMES, or USER PRESET.
- 5) Once you have highlighted GENERAL USE or GAMES, press the button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.



- 6a) ?If USER PRESET is highlighted, press the button to highlight RED. Next, press the or button to adjust the color red.
- 6b) ?When finished with RED, press the button to highlight GREEN. Next, press the or button to adjust the color green.
- 6c) ?When finished GREEN, press the button to highlight BLUE. Next, press the or button to adjust the color blue.
- 6d) ?When all adjustments are complete, press the button to confirm your adjustments and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS. . .
... to continue to RESET TO FACTORY SETTINGS, press the button until RESET TO FACTORY SETTINGS is highlighted. Next, start with step 3 under RESET TO FACTORY SETTINGS.
... to exit completely, press the button.

RESET TO FACTORY SETTINGS


RESET TO FACTORY SETTINGS returns everything in all the windows to factory presets.

- 1) Press the button on the monitor. The MAIN CONTROLS window appears.
- 2) Press the button until RESET TO FACTORY SETTINGS is highlighted.



3) Press the button. The RESET TO FACTORY SETTINGS window appears.

- 4) Press the or button to select YES or NO. NO is the default. YES returns all settings to their original factory adjustments.



- 5) Press the button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to EXTRA CONTROLS, press the button until EXTRA CONTROLS is highlighted. Next, start with step 3 under EXTRA CONTROLS.

. . . to exit completely, press the button.

EXTRA CONTROLS


DEGAUSS

EXTRA CONTROLS is a set of three features, including DEGAUSS. Degaussing removes electromagnetic build up that may distort the color on your screen.

- 1) Press the button on the monitor. The MAIN CONTROLS window appears.
2) Press the button until EXTRA CONTROLS is highlighted.



- 3) Press the button. The EXTRA CONTROLS window appears. DEGAUSS will be highlighted.



- 4) To degauss your screen, press the button. Your screen will be degaussed, then the MAIN CONTROLS window will reappear. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to ADJUST MOIRE, press the button until EXTRA CONTROLS is highlighted. Next, start with step 3 under EXTRA CONTROLS, ADJUST MOIRE.

. . . to exit completely, press the button.

ADJUST CONVERGENCE (Not available in all models)

EXTRA CONTROLS is a set of features, including ADJUST CONVERGENCE. Convergence is a process by which a color is created by blending other colors. For example, white is created by blending red, blue, and green. If these colors do not completely blend together (converge) then you may see unwanted red, green, or blue lines or dots. To adjust the convergence, follow the steps below. Note: Use only if necessary. Remember: you must degauss the monitor BEFORE adjusting the convergence.


- 1) Press the button on the monitor. The MAIN CONTROLS window appears.

- 2) Press the button until EXTRA CONTROLS is highlighted.




- 3) Press the button. The EXTRA CONTROLS window appears. DEGAUSS is highlighted. Note: If you have not degaussed the monitor, please follow the steps under the Extra Controls - Degauss section of this manual before adjusting the convergence.

- 4) Press the button until ADJUST CONVERGENCE is highlighted.





- 5) Press the button. The ADJUST CONVERGENCE window appears. ADJUST HORIZONTAL is highlighted.




- 6) To adjust the horizontal convergence, press the or button.

◀◀ Go to cover page

7) When the horizontal convergence is adjusted, press the  button to highlight VERTICAL CONVERGENCE.




8) To adjust the vertical convergence, press the  or  button.

9) When the vertical convergence is adjusted, press the  button to


return to the EXTRA CONTROLS window. BACK TO MAIN CONTROLS is highlighted.

Smart Help

After returning to EXTRA CONTROLS . . .


. . . to continue to ADJUST PURITY, press the  button until ADJUST PURITY is highlighted. Next, start with step 4 under EXTRA CONTROLS - ADJUST PURITY.

Note: If you have not degaussed the monitor, please follow the steps under the Extra Controls - Degauss section of this manual before adjusting the purity.

. . . to exit completely, press the  button twice.

ADJUST PURITY (Not available in all models)

EXTRA CONTROLS is a set of features, including ADJUST PURITY. Purity is a process by which colors appear clear and untainted, especially in the four corners of the monitor. Purity can be affected by such things as the presence of a magnetic source near the monitor or even by the ambient room temperature. For example, you might see the color red in a corner of the monitor screen where you should see only a pure white. To adjust the purity, follow the steps below. Note: Use only if necessary. Remember: you must degauss the monitor BEFORE adjusting the purity.

1) Press the  button on the monitor. The MAIN CONTROLS window appears.


2) Press the  button until EXTRA CONTROLS is highlighted.




3) Press the  button. The EXTRA CONTROLS window appears.



DEGAUSS is highlighted. Note: If you have not degaussed the monitor, please follow the steps under the Extra Controls - Degauss section of this manual before adjusting the purity.


4) Press the  button until ADJUST PURITY is highlighted.




5) Press the  button. The ADJUST PURITY window appears. TOP LEFT is highlighted.





6) To adjust the top left purity, press the  or  button.


7) When the top left purity is adjusted, press the  button to highlight TOP RIGHT.





8) To adjust the top right purity, press the  or  button.

9) When the top right purity is adjusted, press the  button to highlight BOTTOM LEFT.



10) To adjust the bottom left purity, press the  or  button.

11) When the bottom left purity is adjusted, press the  button to highlight BOTTOM RIGHT.



- 12) To adjust the bottom right purity, press the or button.
- 13) When the bottom right purity is adjusted, press the button to return to the EXTRA CONTROLS window. BACK TO MAIN CONTROLS is highlighted.

Smart Help
After returning to EXTRA CONTROLS . . .
. . . to continue to ADJUST PURITY, press the button until AUTO CALIBRATE is highlighted. Next, start with step 4 under EXTRA CONTROLS - AUTO CALIBRATE.
. . . to exit completely, press the button twice.


ADJUST MOIRE (Not available in all models)

EXTRA CONTROLS is a set of three features, including ADJUST MOIRE. Moire is a fringe pattern arising from the interference between two superimposed line patterns. To adjust your moire, follow the steps below. Note: Use only if necessary. By activating ADJUST MOIRE, sharpness can be affected.


- 1) Press the button on the monitor. The MAIN CONTROLS window appears.
- 2) Press the DOWN CURSOR button until EXTRA CONTROLS is highlighted.



- 3) Press the button. The EXTRA CONTROLS window appears. DEGAUSS will be highlighted.
- 4) Press the button until ADJUST MOIRE is highlighted.




- 5) Press the button. The ADJUST MOIRE window appears. HORIZONTAL will be highlighted.



- 6) To adjust the horizontal moire, press the or button.

Go to cover page

7) When the horizontal moire is adjusted, press the button to highlight VERTICAL.



- 8) To adjust the vertical moire, press the or button.
- 9) When the vertical moire is adjusted, press the button to return to the EXTRA CONTROLS window. BACK TO MAIN CONTROLS will be highlighted.


Smart Help After returning to MAIN CONTROLS . . .
. . . to exit completely, press the button.

CLOSE MAIN CONTROLS



To lock (disable) OSD function:

- Press OSD button " " for over 15 seconds to lock the OSD function. Release it, then OSD comes on the screen as below.



To unlock (enable) OSD function:

- Press OSD button " " for over 15 seconds again to unlock the OSD function. Release it, then OSD comes on the screen as below.

Disable the WARNING SIGNAL & Access Service mode (burn in mode) :

The WARNING SIGNAL of appeared :

- After disconnect the Interface cable of the monitor,then Monitor is powered ON.
- If it is successful, the signal " " comes on the screen again later.


To disable all the WARNING SIGNAL :

- Connect the Interface cable of the monitor (Monitor is ON.).
- If it is successful, then the signal " "disappeared.

Access Service Mode & Burn in mode

Firstly, get into Factory Adjustment Mode.

Push LEFT & RIGHT buttons at the same time for over 15 seconds and release them.
The factory message appears at the bottom of the main OSD menu. (for example ;
 is M.T.B.F. in HOUR unit)




- Disconnect the Interface cable of the monitor.
- Push LEFT & RIGHT buttons at the same time,then power ON.
- If it is successful, the signal " " comes on the screen later. (Background is white.).
- In the beginning of service mode (full white pattern), the monitor will working at 48kHz of horizontal frequency,after 55 seconds, it will switch to 81kHz automatically, then change mode between two modes constantly every 55 seconds.

-Leave "burn in MODE" :
Reconnect the interface cable to PC, then the "burn in MODE" disappear.

The OSD Tree


Below is an overall view of the structure of the On-Screen Display. You can use this as reference when you want to later on work your way around the different adjustments.



* Specifications are subject to change without prior notice.


Go to cover page

Front View



- Power button switches your monitor on.
- OK button which when pressed will take you to the OSD controls
- Contrast hotkey. When the UP arrow is pressed, the adjustment controls for the CONTRAST will show up.
- UP and DOWN buttons are used when adjusting the OSD of your monitor
- Brightness hotkey. When both the LEFT and RIGHT arrows are pressed at the same time, then the adjustment controls for BRIGHTNESS will show up.
- LEFT and RIGHT buttons, like the UP and DOWN buttons, are also used in adjusting the OSD of your monitor.

Rear View



- Power in - attach power cable here.
- Video In - this is a cable which is already attached to your monitor. Connect the other end of the cable to your PC.

On-Screen Display

[Description of the On-Screen Display](#) [The OSD Tree](#) [The OSD Controls](#)


Description of the On Screen Display

What is the On-Screen Display?

This is a feature in all Philips monitors which allows an end-user to adjust screen performance of monitors directly through an on-screen instruction window. The user interface provides user-friendliness and ease-of-use when operating the monitor.

Basic and simple instruction on the control keys.

On the front controls of your monitor, once you press the OK button, the On Screen Display (OSD) Main Controls window will pop up and you can now start making adjustments to your monitor's various features. Use the left and right arrow buttons to make your adjustments within.



The OSD Tree

Below is an overall view of the structure of the On-Screen Display. You can use this as reference when you want to later on work your way around the different adjustments.

Technical Specification*

CRT

Size and deflection :17 inch/41cm,90°deflection angle
Dot pitch : 0.25mm


Tube type Aperture grille,flat ,high contrast,
anti-glare,anti-static,anti-
reflection,light transmission 38%
Phosphor : B22

Recommended display
area : 12.0"x9.0"/306 x 230 mm
Maximum display area : 12.8"x9.6"/325 x 244 mm

Scanning
Horizontal scanning : 30 - 92 KHz
Vertical scanning : 50 - 160 Hz

Video
Video dot rate : 234 Mhz
Input impedance
-Video : 75 Ohm
- Sync : 2.2 kOhm
Input signal levels : 0.7Vpp
Sync input levels : Separate sync
Composite sync
Sync polarities : Positive and negative

Pin assignment :



The 15-pin D-sub connector(male) of the signal cable :

Pin No.	Assignment	Pin No.	Assignment
1	Red video input	9	No pin present
2	Green video input	10	Logic Ground
3	Blue video input	11	Identical output- Connected to pin 10
4	Identical output- Connected to pin 10	12	Serial data line(SDA)
5	Ground	13	H.Sync
6	Red video ground	14	V.Sync(VCLK for DDC)
7	Green video ground	15	Data clock line(SCL)
8	Blue video ground		

Data Storage

Factory preset mode:

This monitor has 9 factory-preset modes as indicated in the following table :

	Mode	Resolution	Frequen		Sync polarity	
			H(KHz)	V(Hz)	H	V
M01	VGA	640 x 350	31.5	70	-	+
M02	VGA	640 x 400	31.5	70	-	+
M03	VGA	640 x 480	43.2	85	-	-
M04	SVGA	800 x 600	46.9	75	+	+
M05	SVGA	800 x 600	53.7	85	+	+
M06	EVGA	1024 x 768	60.0	75	+	+
M07	EVGA	1024 x 768	68.7	85	+	+
M08	VESA	1280 x 1024	80.0	75	+	+
M09	VESA	1280 x 1024	91.1	85	+	+

White Color Temperature

Chromaticity CIE coordinates:
at 9300 °K x = 0.283 y = 0.297
at 6500 °k x = 0.313 y = 0.329
at 5500 °k x = 0.332 y = 0.347

Power Management

Complies with EPA Energy Star and NUTEK specifications
Typical operation : 92 W
Suspend/Standby Mode : < 15 W
Off Mode : < 3 W

Physical Specifications

Dimensions : 399x373x419mm(excluding base)
: 399x410x419mm(including base)
Net weight : 17.5 Kg
Power supply : 90 - 264 VAC, 50/60HZ
Power consumption : 92 Watt
Operating condition
Temperature : 0 °C ~ 35 °C
Humidity : 10 % ~ 90 %(W/O condensation)
Storage condition
Temperature : - 25 °C ~ 65 °C
Humidity : 10 % - 90 % (W/O condensation)

Automatic Power Saving

If you have VESA's DPMS compliance display card or software installed in your PC,the monitor can automatically reduce is power consumption when not in use. And if an input from keyboard, mouse or other input devices os detected, the monitor will automatically "wake up". The following table shows the power consumption and signalling of this automatic power saving feature :

Power Management Definition						
VESA's mode	VIDEO	H-SYNC	V-SYNC	POWER USED	POWER SAVING(%)	LED COLOR
ON	Active	Yes	Yes	< 92 W	0 %	Green
Stand-by	Blanked	No	Yes	< 15 W	> 84 %	Yellow
Suspend	Blanked	Yes	No	< 15 W	> 84 %	Yellow
OFF	Blanked	No	No	< 3 W	> 97 %	Amber

This monitor is Energy Star compliant .As an ENERGY STAR Parttner, PHILIPS has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

TELEVISION/MONITOR SAFETY GUIDELINES FOR THE PROFESSIONAL SERVICE TECHNICIAN

Safety Checks

After the original service problem has been corrected, a complete safety check should be made. Be sure to check over the entire set, not just the areas where you have worked. Some previous service may have left an unsafe condition, which could be unknowingly passed on to your customer. Be sure to check all of the following:

Fire and Shock Hazard

1. Be sure all components are positioned in such a way as to avoid the possibility of adjacent component shorts. This is especially important on those chassis which are transported to and from the service shop.
2. Never release a repaired unit unless all protective devices such as insulators, barriers, covers, strain reliefs, and other hardware have been installed in accordance with the original design.
3. Soldering and wiring must be inspected to locate possible cold solder joints, solder splashes, sharp solder points, frayed leads, pinched leads, or damaged insulation (including the ac cord). Be certain to remove loose solder balls and all other loose foreign particles.
4. Check across-the-line components and other components for physical evidence of damage or deterioration and replace if necessary. Follow original layout, lead length, and dress.
5. No lead or component should touch a receiving tube or a resistor rated at 1 watt or more. Lead tension around protruding metal surfaces or edges must be avoided.
6. Critical components having special safety characteristics are identified with an asterisk by the Ref. No. in the parts list and enclosed within a broken line * (where several critical components are grouped in one area) along with the safety symbols on the schematic diagrams and/or exploded views.
7. When servicing any unit, always use a separate isolation transformer for the chassis. Failure to use a separate isolation transformer may expose you to possible shock hazard, and may cause damage to servicing instruments.
8. Many electronic products use a polarized ac line cord (one wide pin on the plug.) Defeating this safety feature may create a potential hazard to the service and the user. Extension cords which do not incorporate the polarizing feature should never be used.
9. After reassembly of the unit, always perform an leakage test or resistance test from the line cord to all exposed metal parts of the cabinet. Also check all metal control shafts (with knobs removed), antenna terminals, handles, screws, etc. to be sure the unit may be safely operated without danger of electrical shock.

* Broken line

Implosion

1. All picture tubes used in current model receivers are equipped with an integral implosion system. Care should always be used, and safety glasses worn, whenever handling any picture tube. Avoid scratching or otherwise damaging the picture tube during installation.
2. Use only replacement tubes specified by the manufacturer.


X-radiation

1. Be sure procedures and instructions to all your service personnel cover the subject of X-radiation. Potential sources of X-rays in TV receivers are the picture tube and the high voltage circuits. The basic precaution which must be exercised is to keep the high voltage at the factory recommended level.
2. To avoid possible exposure to X-radiation and electrical shock, only the manufacturer's specified anode connectors must be used.
3. It is essential that the service technician has an accurate HV meter available at all times. The calibration of this meter should be checked periodically against a reference standard.
4. When the HV circuitry is operating properly there is no possibility of an X-radiation problem. High voltage should always be kept at the manufacturer's rated value - no higher - for optimum performance. Every time a color set is serviced, the brightness should be run up and down while monitoring the HV with a meter to be certain that the HV is regulated correctly and does not exceed the specified value. We suggest that you and your technicians review test procedures so that HV regulation are always checked as a standard servicing procedure, and the reason for this prudent routine is clearly understood by everyone. It is important to use an accurate and reliable HV meter. It is recommended that the HV recorded on each customer's invoice, which will demonstrate a proper concern for the customer's safety.
5. When troubleshooting and making test measurements in a receiver with a problem of excessive high voltage, reduce the line voltage by means of a Variac to bring the HV into acceptable limits while troubleshooting. Do not operate the chassis longer than necessary to locate the cause of the excessive HV.

6. New picture tubes are specifically designed to withstand higher operating voltages without creating undesirable X-radiation. It is strongly recommended that any shop test fixture which is to be used with the new higher voltage chassis be equipped with one of the new type tubes designed for this service. Addition of a permanently connected HV meter to the shop test fixture is advisable. The CRT types used in these new sets should never be replaced with any other types, as this may result in excessive X-radiation.
7. It is essential to use the specified picture tube to avoid a possible X-radiation problem.
8. Most TV receivers contain some type of emergency "Hold Down" circuit to prevent HV from rising to excessive levels in the presence of a failure mode. These various circuits should be understood by all technicians servicing them, especially since many hold down circuits are inoperative as long as the receiver performs normally.

Leakage Current Cold Check

1. Unplug the ac line cord and connect a jumper between the two prongs of the plug.
2. Turn on the power switch.
3. Measure the resistance value between the jumpered ac plug and all exposed cabinet parts of the receiver, such as screw heads, antennas, and control shafts. When the exposed metallic part has a return path to the chassis, the reading should be between 1 megohm and 5.2 megohms. When the exposed metal does not have a return path to the chassis, the reading must be infinity. Remove the jumper from the ac line cord.



Leakage Current Hot Check

1. Do not use an isolation transformer for this test. Plug the completely reassembled receiver directly into the ac outlet.
2. Connect a 1.5k, 10w resistor paralleled by a 0.15uf. capacitor between each exposed metallic cabinet part and a good earth ground such as a water pipe, as shown above.
3. Use an ac voltmeter with at least 5000 ohmsy volt sensitivity to measure the potential across the resistor.
4. The potential at any point should not exceed 0.75 volts. A leakage current tester may be used to make this test; leakage current must not exceed 0.5 milliamps. If a measurement is outside of the specified limits, there is a possibility of shock hazard. The receiver should be repaired and rechecked before returning it to the customer.
5. Repeat the above procedure with the ac plug reversed. (Note: An ac adapter is necessary when a polarized plug is used. Do not defeat the polarizing feature of the plug.)

Picture Tube Replacement

The primary source of X-radiation in this television receiver is the picture tube. The picture tube utilized in this chassis is specially constructed to limit X-radiation emissions. For continued X-radiation protection, the replacement tube must be the same type as the original, including suffix letter, or a Philips approved tube.

Parts Replacement

Many electrical and mechanical parts in Philips television sets have special safety related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. The use of a substitute part which does not have the same safety characteristics as the Philips recommended replacement part shown in this service manual may create shock, fire, or other hazards.

WARNING : Before removing the CRT anode cap, turn the unit **OFF** and short the HIGH VOLTAGE to the CRT DAG ground.
SERVICE NOTE : The CRT DAG is not at chassis ground.